


MODEL 312000x98A

REPAIR PARTS CHASSIS & HOOD




MODEL 312000x98A

REPAIR PARTS CHASSIS & HOOD

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	690566	27	Lens, Left	094081
2	Cap, Push On	028x23	28	Bezel	094807 Z
3	Spring	094057	29	Lens, Right	094080
4	Screw	26x229	30	Bumper	094744
5	Bolt, Wing	1001054	31	Screw	26x270
6	Washer	017x47	32	Screw	26x238
7	Bolt, Shoulder	009x56	33	Bearing, Steering	1001491
8	Support, Seat	094154E700	34	Dash	094074E700
9	Rod, Pivot	094156 Z	35	Screw	26x201
10	Bracket, Pivot	094153E700	36	Panel, Access	093007E700
11	Bolt	001x45	37	Support, Dash	095318E700
12	Nut	015x89	38	Bracket, Rear Hanger	1001270E700
13	Bolt, Shoulder	009x55	39	Support, Left Grille	094083E700
14	Washer	094155 Z	40	Axle, Hanger	094007E700
15	Spring	164x31	41	Support, Right Grille	094082E700
16	Screw	26x249	42	Bolt, Shoulder	009x58
17	Screw	26x263	43	Frame, Right	1001268E701
18	Spring	164x30	44	Frame, Left	1001269E701
19	Deck, Seat	095249E245	45	Container, Battery	690424
20	Nut	015x88	46	Plate, Hitch	1001002E700
21	Plate, Index	094151E700	47	Panel, Rear	690434E700
23	Mat, Left	094999	49	Nut	015x81
24	Mat, Right	094998	50	Screw	26x277
25	Hood	1001492E245	—	Instruction Book & Parts List	F-020721L
26	Grille	094079E700			

MODEL 312000x98A

REPAIR PARTS MOTION DRIVE



MODEL 312000x98A

REPAIR PARTS MOTION DRIVE


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Bolt, Shoulder	009x39	32	Pin, Hair	0031x6
2	Nut, Hex	015x89	33	Washer	017x38
3	Arm, Idler	690273	35	Bolt	06x105
4	Rod, Clutch	094041 Z	36	Transaxle **	—
5	Nut	015x79	37	Nut	015x88
6	Washer	17x102	38	Key, Woodruff	020697
7	Grip	092697	39	Bolt	01x155
8	Pin, Cotter	030x20	40	Bracket, Transaxle	094008E700
9	Lever, Shift	094043 Z	41	Pulley	690409
10	Washer	017x47 Z	42	Bracket, Transaxle Support	094433
11	Link, Shift	094044 Z	43	E-Ring	0011x7
12	Nut, Adjuster	021920	44	Pulley, Drive	095094
13	Grip	091079	45	Key, Square	021553
14	Rod, Parking Brake	1001271 Z	46	Washer	17x160
15	Nut, Adjuster	094815	47	Spacer, Transaxle	690554 Z
16	Bracket, Shift Pivot	1001303 Z	48	Stem, Valve	024373
17	Screw	26x249	49	Tire *	776114
18	Nut	015x84	—	Tube	407049
19	Mount, Stud Spring	094042 Z	50	Wheel & Tire Assembly	690376-601
20	Bolt, Shoulder	009x54	51	Washer	17x195
21	Spring, Extension	165x116	52	E-Ring	0011x3
22	Bracket, Right Shifter	1001302E700	53	Hub Cap	094618
23	Frame, Right	1001268E701	54	Guide, Belt	093349
24	Bolt, Carriage	002x53	55	Pin, Hair	031x4
25	Frame, Left	1001269E701	56	Spring, Extension	165x141
26	Latch, Parking Brake	094045 Z	57	Spring, Extension	165x92
27	Pedal	021544	58	Screw	26x216
28	Lever, Brake/Clutch	094038E700	59	Washer	17x148
29	Bracket, Pedal	1001117E700	60	Screw	26x267
30	Belt, Motion Drive	037x87	61	Washer	17x169
31	Yoke, Shift	094031 Z			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** For information on Replacement Parts see the Central Parts Distributor in your area.

MODEL 312000x98A

REPAIR PARTS STEERING




MODEL 312000x98A

REPAIR PARTS STEERING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	095336	23	Washer	17x104
2	Post, Steering	690625	24	Washer	017x530 Z
3	Insert, Steering Wheel	095338	25	Nut, Flange	015x84
4	Bearing	094124	26	Axle Assembly	690210E700
5	Nut, Flange	15x111	27	Drag Link, Left	95329E700
6	Bolt, Shoulder	009x57	28	Spindle Assembly, Right	1001298E700
7	Gear, Pinion	690183E700	29	Drag Link, Right	095328E700
8	Ring, Snap	011x25	30	Screw	026x249
9	Gear, Sector	094121E700	31	Bearing, Wheel	091334
10	Bearing	094123	32	Stem, Valve	024373
11	Bolt	001x84	33	Tire *	090594
12	Plate, Steering	1001121E700	—	Tube	407046
13	Plate, Engine	094006E700	34	Wheel and Tire Assembly	690377-601
14	Nut, Flange	015x88	35	Washer	17x195
15	Nut, Flange	15x118	36	Washer	17x113
16	Bracket, Hanger	1001270E700	37	Washer	017x83
17	Axle, Hanger	094007E700	38	Hub Cap	094618
18	Bolt	01x146	39	Screw	26x267
19	Pin, Cotter	030x49	40	Bellows	092059
20	Bearing	690150	41	Bolt	0025x3
21	Spindle Assembly, Left	1001299E700	42	Washer	17x146
22	Bolt	01x111			

MODEL 312000x98A

REPAIR PARTS MOWER HOUSING SUSPENSION




MODEL 312000x98A

REPAIR PARTS MOWER HOUSING SUSPENSION

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Grip	092698	26	Bolt, Hex	001x74
2	Handle, PTO	094346 Z	27	Arm Assembly, Right Lift	690386E700
3	Pad, Switch	094022 Z	28	Arm, Right Lift	094180E700
4	Bolt	0025x3	29	Plate, Lift Arm	094030E700
5	Grip	092697	30	Pin	094067
6	Spring	166x40	31	Bracket, Rear Suspension	094055E700
7	Washer	17x103	32	Bushing, Lift Tube	094065
8	Handle, Lift	690533 Z	33	Bolt, Shoulder	009x53
9	Lever, PTO	094017 Z	34	Bracket, Pivot	094015E700
10	Bolt, Shoulder	009x39	36	Washer	17x191
11	Pin, Cotter	030x20	37	Nut, Flange	015x84
12	Washer	17x102	38	Spring	165x117
13	Link, PTO	094004 Z	39	Nut, Flange	015x68
14	Nut, Flange	015x84	40	Bracket, PTO	094005E700
15	Screw	26x249	41	Hanger, Right Deck	094026E700
16	Spring	166x39	42	Hanger, Left Deck	094027E700
17	Bracket, PTO	094018E700	43	Rod, Hanger	094158 Z
18	Spring	165x116	44	Hanger, Front	690381E700
19	Crank, PTO	690394E700	45	Nut, Flange	015x89
20	Link, Lift	094053E700	46	Pin, Cotter	030x49
21	Link, Lift Handle	094028E700	47	Pin, Threaded Shoulder	690382
22	Nut, Flange	15x118	48	Screw	26x49
23	Washer	017x57	49	Bolt, Hex	01x106
24	Pin, Hair	0031x4	50	Washer	017x38
25	Washer	017x91	51	Plate, Weight	690370E700

MODEL 312000x98A

REPAIR PARTS MOWER HOUSING




MODEL 312000x98A

REPAIR PARTS MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Pulley	690432	29	Baffle	690399E700
2	Nut, Flange	015x84	30	Nut, Flange	015x89
3	Nut	15x121	31	Strap, Rubber	054695
4	Belt, Blade	037x74	32	Screw	01x139
5	Pulley, Idler	690387	33	Extension, Chute	690367
6	Mandrel	094129	34	Nut	015x79
7	Screw	0025x7	35	Spring, PTO	165x118
8	Guide, Belt	092424	36	Spring, Extension	165x140
9	Spacer	094130	37	Nut, Flange	15x84
10	Bracket, Rear Suspension	094055E700	38	Bracket, Front Deck	690380E700
11	Bolt, Shoulder	009x52	39	Pin, Threaded Shoulder	094067
12	Knob	094068	40	Washer	017x91
13	Washer	017x45	41	Pin, Hair	0031x4
14	Bolt, Shoulder	009x51	42	Hanger, Front	690381E700
15	Plate, Suspension	690379E700	43	Housing, Jackshaft	094305
16	Pad, Friction	094137	44	Fan, Assist	690359
17	Spring	166x43	45	Housing, Fan	690360
18	Nut, Flange	015x79	46	Washer	017x37 Z
19	Bracket, Rear Deck	690378E700	47	Bolt	001x71
20	Pin, Hanger	095194	48	Bolt	01x106
21	Link, Lift	094053	49	Nut	15x100
22	Nut	15x116	50	Washer	17x165
23	Bracket, Idler Arm	690427E700	51	Washer, Belleville	17x166
24	Assembly, Idler Arm & Pad	690647	52	Blade	690398E701
25	Screw	26x249	53	Adapter, Blade	092466
26	Bolt, Shoulder	009x39	54	Bolt	01x121
27	Bolt, Carriage	002x64	1-54	Blade Housing, Complete	776110
28	Housing, Blade	690596			

MODEL 312000x98A

REPAIR PARTS ENGINE MOUNT




MODEL 312000x98A

REPAIR PARTS ENGINE MOUNT

Key No.	Description	Part No.
1	Fuel Cap	092317
2	Fuel Tank	094073
3	Hose Clamp	095197
4	Fuel Line	023717
5	Hose Clamp	095197
6	Screw	26x201
7	Plate, Engine	094006E700
8	Throttle Control	091989
9	Engine	—
10	Bolt, Engine Mount	0025x7
11	Stack Pulley Assembly	690439 Z
12	Lockwasher	019x35
13	Bolt, Hex	1x140
14	Washer	17x170
15	Screw	26x249
16	Gasket	091309
17	Muffler	091271
18	Deflector, Muffler	1001350
19	Screw	26x208
20	Bolt, Hex	01x134
21	Guide, Belt	094384
22	Nut, Flange	015x79 Z
23	Guide, Belt	094066
24	Shield, Heat	091277
26	Screw	26x253
25	Spacer	093077

MODEL 312000x98A

REPAIR PARTS ELECTRICAL SYSTEM




MODEL 312000x98A

REPAIR PARTS ELECTRICAL SYSTEM

Key No.	Description	Part No.
1	Harness, Light Wire	250x92
	Socket, Light	092372
	Bulb, Light	090084
2	Harness, Chassis Wire	250x93
3	Switch, Ignition	092377
	Key, Ignition	200729
	Nut, Hex	091489
	Cap, Ignition	091488
4	Switch, Limit	094136
5	Fuse	054212
	Holder, Fuse	407078
6	Solenoid	094613
	Screw, Mounting	026x229
	Locknut	15x116
7	Cable, Battery Ground	024x32
	Screw, Ground Cable	26x213
8	Battery	021075
	Bolt, Carriage	002x82
	Wingnut	14x79
9	Harness, Seat Switch Wire	250x94
10	Switch, Seat Sensor	094159
11	Cable	024x31
12	Switch, Bag Sensor	0690106

MODEL 312000x98A

REPAIR PARTS GRASS BAGGER



MODEL 312000x98A

REPAIR PARTS GRASS BAGGER

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Tube, Top	690404	16	Washer	17x185
2	Bolt	01x121	17	Latch, Spring	690402
3	Nut	15x116	18	Pan, Rear	690362E700
4	Strut, Bag	690433	19	Bolt, Carriage	002x53
5	Nut, Flange	015x79	20	Bracket, Bagger Mounting	690355E700
6	Fastener, Panel	193x1	21	Screw	01x127
7	Seal, Bag (Right End)	690491	22	Plate, Hitch Extension	1001000E700
8	Seal, Bag (Center)	690492	23	Bracket, Lower Mounting	1001001E700
9	Seal, Bag (Left End)	690493	24	Plate, Hitch	1001002E700
10	Hinge	690356E700	25	Nut	015x41
11	Screw	26x249	26	Pin, Latch	054563
12	Assembly, Bag Frame	690403	27	Bolt, Carriage	002x39
13	Bracket, Switch	690400E700	28	Tube, Connecting	690368
14	Bolt, Carriage	002x82	29	Grommet, Extension Tube	690429
15	Nut, Flange	015x89	30	Bag, Grass	690438

MODEL 312000x98A**REPAIR PARTS
DECALS**

Ke No.	Description (Location)	Part No.	Qty.
--	DEKA	44x7197	1
--	12 HP B & S	44x7381	1
--	MURRAY 120/76cm	48X754	1
--	MURRAY 120/76cm	48X755	1
--	Cut Finger	44x5430	1
--	Warranty Symbols	44x6815	1
--	1-6 Height Adjust – Lift Lever	44x6546	1
--	Deck Leveling	44x7027	1
--	No Step	44x5429	1
--	Brake / Clutch	44x5437	1
--	B & S Logo	44x6277	2
--	5 Speed Transaxle	44x6278	1
--	Heat Shield Warning	44x5936	1
--	Drawbar Warning	48x511	1
--	Warning –Pinch Point	44x6828	1
--	TUV & GS European Xport	44x2929	1
--	Dash Symbols	44x6717	1
--	Gas Gauge	44x6595	1
--	MURRAY	48x864	1
--			