



1  
 2  
 3  
 4



PARTS HAVE BEEN MADE INTERCHANGEABLE FOR SERVICE.

*Handwritten:*  
 1610063905  
 1473H  
 Schaller  
 14732  
 φ 2610364G1  
 1473H

MODEL 1473H1-2 · 1474H1 · RATCHETING DRILL



1473H1-2 & 1474H1


60315	2	screw	vis
61496	2	brush holder	porte charbon
61550	2	hex nut	écrou
61561	2	screw	vis
61584	1	washer	roulement à billes
62119	2	ball bearing	roulement à billes
63799P	1	key	clé
63510	1	cord guard	protection câble
63656	1	spring washer	rouleau ressort
63951	1	ball bearing	roulement à billes
63476	6	self-tapping screw	vis
63491	4	self-tapping screw	vis
63789	2	screw	vis
63952	1	bracket & spring set	plaque de séparation
64785	1	key holder	saire de charbons
64873	1	cord clamp	poire à cde
340657P	1	spring	ressort
361174	2	side handle	poignée
361772	1	bushing	manivelle
361855	1	wire	fil
361856	1	rodic knob	poignée
362334	1	indexing shaft	arbre
362334	1	button	goujon
362344	1	motor housing	carter moteur
362740	1	cover & plug	câble et prise
364334P	1	check & key 1473H	mandrin et cle 1473H
364607	1	field 220 V	inducteur 220 V
364614	1	switch VTS-AE 220 V	interrupteur VTS-AE 220 V
364816	1	brush holder clamp	scric
364816	1	brush holder 1/2 mm	clé
364909	1	brassie set	paire de poignées
364946	1	armature 220 v 5 teeth	induit 220 V 5 dents
364946	1	oil tap. bearing	coaxial
365073	1	bearing plate	plaque de roulement
365079	1	bearing plate	carter avant
365080	1	front housing ass'y.	anti-parasite
365082	1	spring	ressort
365247	1	armature 220V 7 teeth	induit 220V 7 dents
364605	1	front housing for 7 teeth	carter avant pour 7 dents
364610P	1	check & key 1474H	mandrin et cle 1474H
357131P	1	switch VTS-AE 220V	interrupteur VTS-AE 220 V
358507P	1	switch VTS-AE 220V	interrupteur VTS-AE 220 V

Schraube	vis	schroef
Kohlenhalter	porte charbon	koolborste houder
Mutter	écrou	moer
Schraube	vis	schroef
Unterlagscheibe	roulement à billes	onderlegging
Lagelager	roulement à billes	lager
Schlossel	clé	sluwel
Curvedball	roulement à billes	decurvedball
Federling	ressort	veerring
Kugellager	roulement à billes	kugellager
Schraube	vis	schroef
Schraube	vis	schroef
Lufttrennblech	plaque de séparation	luchtrennplaat
Kohlenstift	saire de charbons	set koolborstels
Schlossschalter	poignée	elektrohouder
Kohlenkern	poignée	lebak-kern
Feder	ressort	veer
seal. Manjuffit	poignée	231stafel
laucisw	manivelle	harm
drifts	fil	herud
knopf	poignée	knop
Achse	arbre	as
Stift	goujon	stift
Motorgehäuse	carter moteur	motorhuis
Kabel und Stecker	câble et prise	Kabel en stekker
Bohrfutter und Schlüssel 1473H	mandrin et cle 1473H	boorloop en sleutel 1473H
Disjunctschelle	coaxial	afschakeling
Feld 220 V	inducteur 220 V	veld 220 V
Schalter VTS-AE 220 V	interrupteur VTS-AE 220 V	schakelaar VTS-AE 220 V
Niemer	scric	klein
Schlüssel	clé	stuwel
Draht	fil	draad
Getriebe	paire de poignées	handgreep
Anker 220 V 5 Zähne	induit 220 V 5 dents	anker 220 V 5 tanden
Getriebe	coaxial	afschakeling
Lagerplatte	plaque de roulement	lagerplaat
Vordergehäuse	carter avant	fronthuis
Stierschutz	anti-parasite	ontsticker
Anker 220 V 7 Zähne	induit 220V 7 dents	anker 220 V 7 tanden
Vordergehäuse für 7 Zähne	carter avant pour 7 dents	boorloop met sleutel 1474H
Bohrfutter und Schlüssel 1474H	mandrin et cle 1474H	schakelaar VTS-AE 220V
Schalter VTS-AE 220V	interrupteur VTS-AE 220 V	


**SERVICE**

**LUBRICATION SCHEME**


use grease  
252 (lubri) or 80373P (1481)



**OLD WIRING DIAGRAM**



**NEW WIRING DIAGRAM**



**REPAIR MSTR.**

NEW CONSTRUCTIONS  
 This has been prepared on the basis of  
 drawings of this machine as they are  
 incorporated in the manual. It is  
 intended for use by the repair  
 engineer. It is not intended for use  
 as a reference.

