


TYPE 1



⚠ WARNING


All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530057566	Assy – Throttle Cable	20.	530016014	Screw
2.	530049107	Trigger	21.	530016224	Screw
3.	530058751	Throttle Hsg. (Right)	22.	530096099	Assy – Gearbox
4.	530016406	Screw	23.	530015197	Nut
5.	530015814	Screw	24.	530095772	Assy – Hub.
6.	530015786	Bolt – Handle	25.	530053241	Spring
7.	530054183	Assy – Wire	26.	530401957	Retainer
8.	530150095	Throttle Hsg. (Left)	27.	530056500	Assy – Spool w/Line
9.	530069572	Kit – Switch	28.	530056498	Assy – Head TNG VI Assy.
10.	530058754	Handle – Assist	Not Shown		
11.	530016152	Wingnut – Handle			
12.	530071942	Assy – Drive Shaft Hsg.			
13.	530096169	Shaft – Flex			
14.	530056401	Wrench			
15.	530052285	Line Limiter			
16.	530015814	Screw			
17.	530071823	Kit – Shield Assy (Incl.15,16)			
18.	530015820	Bolt – Shield			
19.	530057554	Bracket – Shield			
				Operator Manual	
				(Euro)	
				(Scan)	
				(Euro III)	
				(Euro IV)	
				(Turkish)	
				Decal – Shaft Warning	

✓ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

TYPE 2




⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530057566	Assy - Throttle Cable	20.	530015775	Screw
2.	530049107	Trigger	21.	530016014	Screw
3.	530058751	Throttle Hsg. (Right)	22.	530096099	Assy - Gearbox
4.	530016406	Screw	23.	530015197	Nut
5.	530015814	Screw	24.	****	Assy - Head
6.	530015786	Bolt - Handle			Not Shown
7.	530054183	Assy - Wire			
8.	530150095	Throttle Hsg. (Left)			
9.	530069572	Kit - Switch			
10.	530058754	Handle - Assist			
11.	530016152	Wingnut - Handle			
12.	530071942	Assy - Drive Shaft Hsg.			
13.	530096169	Shaft - Flex			
14.	530056401	Wrench		---	Operator Manual
15.	530052286	Line Limiter		545123514	(Euro)
16.	530015814	Screw		545123513	(Scan)
17.	545006030	Kit - Shield Assy (Incl.15,16)		545123515	(Euro III)
18.	530015820	Bolt - Shield		545123516	(Euro IV)
19.	545150701	Bracket - Shield		545123517	(Turkish)
				530150303	Decal - Shaft Warning

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)


TYPE 1



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015880	Screw	21.	530058912	Cover-Air Box	45.	530071785	Kit-Con Rod/Piston (Incl. 10,46)
2.	530058982	Bolt-Muffler	22.	530039234	Ignition Module	46.	530069945	Kit-Conn. Rod Assy
3.	530059826	Assy-Muffler/Shield (Incl. 2)	23.	530027953	Coupling-Drive	47.	530071750	O-Ring-C'case (kit)
4.	530015953	Screw-Cylinder	24.	530016357	Screw	48.	530058738	Assy-Plug (incl.47)
5.	952030249	Spark Plug (RCJ 6Y)	25.	530047278	Assy-Leadwire	49.	530016386	Screw
6.	530012541	Cylinder	26.	530016391	Screw	50.	530058737	Shroud-Rear
7.	530071750	Seal-Cylinder (kit)	27.	530071943	Assy.-Fan Hsg	51.	530016431	Retainer-Tank
8.	530055120	Piston Ring	28.	530058742	Handle-Starter	52.	530058847	Assy-Fuel Tank (incl. filter, lines & fuel cap)
9.	530015162	Retainer-Piston Pin	29.	530071798	Kit - Rope	53.	530058743	Assy-Fuel Cap w/ret.
10.	530071833	Kit - Piston (Incl. 8, 9)	30.	530015810	Screw	54.	530069247	Kit-Fuel Line (Small)
11.	530012555	Assy-Crankshaft	31.	530016382	Nut 12-24	55.	530069216	Kit-Fuel Line (Large)
12.	530012582	Assy-Crankcase (Incl. 42-44)	32.	530016381	Screw 12-24	56.	530095646	Assy-Fuel Pickup
13.	530071750	Seal-Cyl/Carb. (kit)	33.	530015805	Screw-Shaft Align.	57.	530071750	Kit-Engine Gasket (Incl. 7,13,16,47)
14.	530057547	Adapter-Carb.	34.	530042086	Spring-Starter			Not Shown
15.	530016309	Screw	35.	530071797	Kit-Starter Pulley			
16.	530071750	Gasket-Carb. (kit)	36.	530057548	Baffle			
17.	530071811	Kit-Carb.(C1U-W19)	37.	530015880	Screw			
(Note: Repair kits are not available for this carburetor)			38.	530015828	Washer-Flat			
18.	530059246	Air Box	39.	530054115	Assy-Flywheel			
19.	530016429	Screw	40.	530071751	Assy-C'case & C'shaft (Incl. 11,12,41)			
20.	530036575	Foam-Air Filter	41.	530015941	Retain. Ring-C'shaft	530058709		Bulb-Purge
			42.	530055728	Outer Bearing			
			43.	530019264	Seal			
			44.	530032125	Inner Bearing			

↗ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

TYPE 2



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015880	Screw	21.	530058912	Cover-Air Box	45.	530071785	Kit-Con Rod/Piston (Incl. 10,46)
2.	530058982	Bolt-Muffler	22.	530039234	Ignition Module	46.	530069945	Kit-Conn. Rod Assy
3.	530059826	Assy-Muffler/Shield (Incl. 2)	23.	530027953	Coupling-Drive	47.	530071750	O-Ring-C'case (kit)
4.	530015953	Screw-Cylinder	24.	530016357	Screw	48.	530058738	Assy-Plug (incl.47)
5.	952030249	Spark Plug (RCJ 6Y)	25.	530047278	Assy-Leadwire	49.	530016386	Screw
6.	530012541	Cylinder	26.	530016391	Screw	50.	530058737	Shroud-Rear
7.	530071750	Seal-Cylinder (kit)	27.	530071943	Assy.-Fan Hsg	51.	530016445	Retainer-Tank
8.	530055120	Piston Ring	28.	530058742	Handle-Starter	52.	530058847	Assy-Fuel Tank (incl. filter, lines & fuel cap)
9.	530015162	Retainer-Piston Pin	29.	530071798	Kit - Rope	53.	530058743	Assy-Fuel Cap w/ret.
10.	530071833	Kit - Piston (Incl. 8, 9)	30.	530015810	Screw	54.	530069247	Kit-Fuel Line (Small)
11.	530012555	Assy-Crankshaft	31.	530016382	Nut 12-24	55.	530069216	Kit-Fuel Line (Large)
12.	530012582	Assy-Crankcase (Incl. 42-44)	32.	530016381	Screw 12-24	56.	530095646	Assy-Fuel Pickup
13.	530071750	Seal-Cyl/Carb.(kit)	33.	530015805	Screw-Shaft Align.	57.	530071750	Kit-Engine Gasket (Incl. 7,13,16,47)
14.	530057547	Adapter-Carb.	34.	530042086	Spring-Starter	Not Shown		
15.	530016441	Screw	35.	530071797	Kit-Starter Pulley	530058709	Bulb-Purge	
16.	530071750	Gasket-Carb. (kit)	36.	545080601	Baffle			
17.	530071811	Kit-Carb.(C1U-W19)	37.	530016386	Screw			
(Note: Repair kits are not available for this carburetor)			38.	530015828	Washer-Flat			
18.	530059246	Air Box	39.	530054115	Assy-Flywheel			
19.	530016429	Screw	40.	530071751	Assy-C'case & C'shaft (Incl. 11,12,41)			
20.	530036575	Foam-Air Filter	41.	530015941	Retain. Ring-C'shaft			
			42.	530055728	Outer Bearing			
			43.	530019264	Seal			
			44.	530032125	Inner Bearing			

↗ = NEW PART NUMBER FOR THIS IPL


* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

PARTS LIST NO. 530165347		 PARTS LIST	MODEL(s) XLT2000 & XLT2000+
DATE 7/31/07	Replaces 530165347 - 01/24/07		Note: Illustration may differ from actual model due to design changes


★★★★ TYPE 2 Service Note: ★★★★★

Some units may have been built with either the TNG VI or TNG VII cutting heads. Please identify the cutting head on your unit and order parts accordingly.

530056498 - Assy - TNG VI Cutting Head



537419207 - Assy - TNG VII Cutting Head



✓ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
 ● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.