




Prod.No: Skand: 995 00 15-10 Exp: 995 00 16-10
 Engine: B & S 135212 Type: 0242 Trim: 01

SPAREPARTS

107 25 48-64



| Pos | Ruta | Ref.nr. | Ref.nr. | Pos | Ruta | Ref.nr. |
|-----|------|--------------|--------------|-----|------|--------------|
| 1 | D | 516 39 69-00 | 515 13 99-46 | 71 | F | 515 13 99-46 |
| 2 | B | 516 40 85-12 | 014 04 59-12 | 72 | A | 515 21 13-90 |
| 3 | B | 516 40 85-12 | 515 21 13-90 | 73 | C | 515 21 14-12 |
| 4 | B | 516 41 16-01 | 515 21 14-68 | 74 | F | 515 21 14-68 |
| 5 | B | 516 41 18-01 | 515 21 14-68 | 75 | F | 515 21 14-70 |
| 6 | B | 516 43 58-00 | 515 21 14-70 | 76 | F | 515 21 14-71 |
| 7 | EC | 516 44 28-01 | 515 21 14-71 | 77 | F | 515 21 22-43 |
| 8 | C | 516 44 50-00 | 515 21 22-43 | 78 | F | 515 21 22-43 |
| 9 | B | 516 50 73-11 | 515 21 23-05 | 79 | F | 515 21 23-05 |
| 10 | D | 516 69 17-11 | 997 10 13-10 | 80 | C | 515 21 23-05 |
| 11 | B | 516 69 60-00 | 515 21 27-99 | 81 | E | 997 10 13-10 |
| 12 | C | 516 69 90-11 | 997 10 05-10 | 82 | E | 515 21 27-99 |
| 13 | B | 516 70 46-11 | 515 21 31-14 | 83 | E | 515 21 31-14 |
| 14 | B | 516 70 47-11 | 515 21 31-92 | 84 | C | 515 21 31-92 |
| 15 | E | 516 70 48-01 | 515 21 31-94 | 85 | C | 515 21 31-94 |
| 16 | E | 516 81 31-00 | 515 21 31-97 | 86 | C | 515 21 31-97 |
| 17 | B | 516 82 62-00 | 516 70 58-01 | 87 | C | 516 70 58-01 |
| 18 | B | 516 82 61-00 | 515 21 34-50 | 88 | C | 515 21 34-50 |
| 19 | B | 516 81 75-00 | 997 10 17-10 | 89 | F | 997 10 17-10 |
| 20 | C | 516 83 12-12 | 021 38 08-12 | 90 | E | 997 10 17-10 |
| 21 | B | 516 86 47-15 | 725 25 03-51 | 91 | D | 021 38 08-12 |
| 22 | B | 516 83 90-00 | 725 25 04-51 | 92 | C | 725 25 03-51 |
| 23 | B | 516 92 51-00 | 725 25 04-51 | 93 | F | 725 25 04-51 |
| 24 | BE | 516 90 69-01 | 725 25 05-51 | 94 | B | 725 25 05-51 |
| 25 | B | 516 92 36-00 | 725 25 07-51 | 95 | BCE | 725 25 07-51 |
| 26 | B | 516 91 16-00 | 725 24 59-51 | 96 | A | 725 24 59-51 |
| 27 | D | 516 91 23-00 | 725 24 89-51 | 97 | C | 725 24 89-51 |
| 28 | D | 516 91 27-00 | 725 24 91-51 | 98 | F | 725 24 91-51 |
| 29 | F | 515 10 41-21 | 725 23 66-51 | 99 | F | 725 23 66-51 |
| 30 | F | 515 10 41-36 | 515 70 16-20 | 100 | F | 515 70 16-20 |
| 31 | A | 515 10 44-57 | 725 24 49-51 | 101 | C | 725 24 49-51 |
| 32 | C | 515 10 44-64 | 725 24 53-51 | 102 | C | 725 24 53-51 |
| 33 | C | 515 10 51-68 | 725 24 55-71 | 103 | A | 725 24 55-71 |
| 34 | C | 515 10 52-54 | 727 64 51-01 | 104 | C | 727 64 51-01 |
| 35 | B | 515 10 53-75 | 515 71 44-12 | 105 | B | 515 71 44-12 |
| 36 | C | 515 10 53-98 | 728 84 47-01 | 106 | CD | 728 84 47-01 |
| 37 | C | 515 10 54-83 | 731 23 20-01 | 107 | C | 731 23 20-01 |
| 38 | F | 515 10 54-87 | 732 21 12-01 | 108 | B | 732 21 12-01 |
| 39 | A | 515 10 56-91 | 732 21 16-01 | 109 | C | 732 21 16-01 |
| 40 | E | 515 10 90-39 | 732 21 18-01 | 110 | AC | 732 21 18-01 |
| 41 | F | 515 10 90-40 | 732 21 20-01 | 111 | BCF | 732 21 20-01 |
| 42 | F | 515 10 90-53 | 732 21 22-01 | 112 | C | 732 21 22-01 |
| 43 | F | 515 10 90-56 | 732 21 16-31 | 113 | F | 732 21 16-31 |
| 44 | C | 516 92 72-00 | 734 11 64-01 | 114 | AC | 734 11 64-01 |
| 45 | C | 515 11 20-33 | 734 11 73-01 | 115 | C | 734 11 73-01 |
| 46 | F | 515 11 20-34 | 734 11 78-01 | 116 | C | 734 11 78-01 |
| 47 | F | 515 11 30-08 | 515 13 97-52 | 117 | C | 515 13 97-52 |
| 48 | F | 515 11 30-10 | 735 11 64-01 | 118 | C | 735 11 64-01 |
| 49 | F | 515 11 30-11 | 735 11 73-50 | 119 | C | 735 11 73-50 |
| 50 | F | 515 11 50-42 | 725 25 50-51 | 120 | C | 725 25 50-51 |
| 51 | F | 515 11 50-45 | 515 74 50-51 | 121 | B | 515 74 50-51 |
| 52 | B | 515 11 50-57 | 734 11 53-01 | 122 | B | 734 11 53-01 |
| 53 | CD | 515 11 60-58 | 516 85 44-12 | 123 | B | 516 85 44-12 |
| 54 | C | 515 11 70-09 | 728 54 14-01 | 124 | C | 728 54 14-01 |
| 55 | C | 515 11 81-53 | | | | |
| 56 | C | 515 11 80-38 | | | | |
| 57 | BE | 515 11 85-87 | | | | |
| 58 | B | 515 12 00-74 | | | | |
| 59 | B | 515 12 32-01 | | | | |
| 60 | B | 515 13 51-65 | | | | |
| 61 | C | 515 13 52-02 | | | | |
| 62 | BC | 515 13 52-25 | | | | |
| 63 | BC | 515 13 90-86 | | | | |
| 64 | CD | 013 94 07-12 | | | | |
| 65 | CC | 515 13 95-15 | | | | |
| 66 | CC | 515 13 95-60 | | | | |
| 67 | CC | 515 13 97-54 | | | | |
| 68 | CF | 515 13 97-67 | | | | |
| 69 | CF | 515 13 97-67 | | | | |
| 70 | C | 515 13 98-39 | | | | |

Färgkod/Colour Code
 xxx xx-08 Vit/White
 xxx xx-12 Gul/Yellow
 xxx xx-11 Grå/Grey
 xxx xx-15 Röd/Red