
LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of two (2) years from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- 1. This warranty does not apply to the engine. Please contact your nearest dealer where they will send the machine to the engine manufacturer.
- 2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by your dealer.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In case of any problem within the boundaries of this warranty, contact the nearest department store, indicate the model number, serial number and the date of purchase of your machine. This warranty does not apply to accidental damages. All implicit warranties are limited to the same time frames. Or contact:

E.M. Services 54 Rue Lambrechts 92400 Courbevoie France Telephone: (1) 46678078 Fax: (1) 46678095

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES. ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN.



REPAIR PARTS MANUAL MODEL NO. M6556SMD MFG. ID. NO. 96121001002 Rotary Lawn Mower







ω

ROTARY LAWN MOWER - - MODEL NUMBER M6556SMD (MFG. ID. NUMBER 96121001002)

KEY	PART		KE		,
NO.	NO.	DESCRIPTION	NO	. NO.	DESCRIPTION
1 5	32 40 32-98	Upper Handle	40	532 40 33-81	Support Bracket, RH
2 5	32 18 35-67	Engine Zone Control Cable	41	532 15 04-06	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1-1/8
3 5	32 75 06-34	Screw	42	532 15 21-24	Spring, Torsion
4 5	32 12 51-62	Bracket, Upstop	43	873 80 04-00	Locknut, Hex
5 5	32 06 64-26	Wire Tie	44	532 41 00-12	Lawn Mower Housing (Includes Key Number 46)
6 5	32 19 19-38	Handle Knob	45	532 14 72-86	Rod, Hinge
8 5	32 19 84-64	Control Bar	46	532 18 91-79	Blade Adapter / Pulley
9 5	32 19 58-00	Support Bracket, Handle, LH	47	532 19 93-79	Blade, 22"
10 5	32 17 09-75	Handle Bracket Assembly, RH	48	532 85 10-74	Washer, Hardened
11 5	32 19 57-99	Support Bracket, Handle, RH	49	532 85 02-63	Washer, Lock, Helical
12 5	32 17 09-77	Handle Bracket Assembly, LH	50	532 85 10-84	Screw, Hex Head 3/8-24 x 1-3/8 (Grade 8)
14 5	32 14 97-41	Screw, Thread Cutting 5/16-18 x 3/4	52	532 18 21-66	Decal, Danger
16 5	32 05 45-83	Screw	54	532 08 83-48	Washer, Flat 1/2
17 5	32 17 71-41	Support Rod	55	532 19 09-39	Mounting Bracket, Debris Shield
18 5	32 13 20-04	Locknut, Keps	56	532 08 58-25	Screw
19 5	32 19 47-88	Rope Guide	57	532 05 17-93	Hairpin Cotter
20 5	32 15 41-47	Footguard	58	532 15 50-44	Lower Handle
24 5	32 06 91-80	Nut, Hex	59	532 19 15-74	Handle Bolt
	32 14 52-12	Locknut, Hex 3/18-16	60		Bolt
27 5	32 40 29-35	Wheel & Tire Assembly	61	532 75 15-92	Locknut, Hex
28 5	32 14 27-48	Shoulder Bolt	62	532 40 58-43	Debris Shield
29 5	32 40 16-30	Belleville Washer	63	532 19 23-25	Screw
30 5	32 40 65-82	Axle Arm Assembly	64		Engine, Briggs & Stratton, Model Number 124K02
	32 08 78-77	Knob, Selector			(Order Parts from Engine Manufacturer)
	32 40 64-28	Spring, Selector	67	532 19 74-80	O-Ring
33 5	32 15 18-89	Mulcher Door	72	532 19 79-91	Clip, Cable
34 5	32 40 16-29	Spacer		532 18 21-34	Warning Decal (not shown)
35 5	32 41 08-07	Bracket, Wheel Adjuster		532 40 04-53	Operator's Manual, European
36 5	32 15 41-32	Bracket, Housing		532 40 04-54	Operator's Manual, Scandinavian
	32 17 65-09	Deflector, Discharge		532 40 04-56	Operator's Manual, East Bloc
39 5	32 40 33-82	Support Bracket, LH		532 40 04-55	Operator's Manual, Baltic
				532 40 98-88	Repair Parts Manual, English



ROTARY LAWN MOWER - - MODEL NUMBER M6556SMD (MFG. ID. NUMBER 96121001002)



ROTARY LAWN MOWER - - MODEL NUMBER M6556SMD (MFG. ID. NUMBER 96121001002)

KE'		DESCRIPTION	KE'		PART NO.		DESCRIPTION	
1	532 19 46-53	Drive Control Cable Assembly	55	53	2 08 60-12		Driveshaft Cover	
2	532 08 80-58	Bearing, Wheel Adjuster	60	53	2 18 34-97	*	Case, Lower	
3	532 14 36-03	Pan Head Tapping Screw #10-24 x 2-3/4	61	53	2 18 34-98	*	Case, Upper	
5	532 14 65-27	V-Belt	62	53	2 18 34-99		Gear, 27 Teeth	
6	532 15 04-95	Spring Retainer	63	53	2 18 35-00		Lever, Clutch	
7	532 19 84-53	Control Bar, Drive	64	53	2 18 35-01		Spring, Return	
9	532 08 39-23	Locknut, Hex	65	53	2 18 35-02		Shaft, Input	
11	532 40 29-36	Wheel & Tire Assembly	66	53	2 18 35-03		Dog, Movable	
12	812 00 00-58	E-Ring	67	53	2 18 35-04		Dog, Fixed	
13	532 40 38-49	Pinion	68	53	2 18 35-05		Wire, Formed	
14	532 18 94-03	Dust Cover	69	53	2 18 35-06		Bearing, Ball	
15	532 19 10-17	Pawl, Drive	70	53	2 18 35-07		Fork, Shift	
16	532 06 77-25	Washer	71	53	2 18 35-08		Seal, Output Shaft	
18	532 08 78-77	Selector Knob	72	53	2 18 35-09		Washer	
28	532 19 58-11	Drive Cover	73	53	2 18 35-10		Seal, Case	
35	532 40 88-03	Kit, Wheel Adjuster, LH	74	53	2 18 35-11		Bushing	
		(Includes Knob and Bearing)	75	53	2 19 65-61		Shaft, Output	
36	532 19 92-06	Gear Case Assembly, Complete	76	53	2 18 35-13		Screw	
38	873 80 04-00	Locknut, Hex 1/4-20	77	53	2 18 35-14		Seal, Input Shaft	
40	532 13 70-90	Spring	78	53	2 19 98-52		Drive Pulley	
41	532 40 88-02	Kit, Wheel Adjuster, RH	79	53	2 19 94-19		Pin, Retaining	
		(Includes Knob and Bearing)						
			* U	* Use Dow Corning #709 to reseal.				

 \mathcal{O}