


Prod.No: 954 06 88 - 01 (P 150 d Tüv)
 Engine: B & S 98982 Type: 0319 Trim: 02


SPARE PARTS

107 25 37-65



Key No.	Part No.	Description
1	5327014-73	Hex Washer Head Screw #10-24 x 1.13
2	5327014-59	Drive Cover
3	5321119-24	Drive Belt
4	5328519-80	Drive Pawl
5	5320880-43	Drive Pulley
6	8120000-30	Retaining Ring
7	5320545-83	Screw 1/4-20 x 1/2
8	5321252-46	Clutch Frame
9	5320509-62	Locknut 1/4-20
10	5321414-29	Clutch Lever
11	5320880-67	Clutch Lever Spacer
12	8736805-00	Locknut 5/16-18
13	8720705-04	Carriage Bolt 5/16-18 x 1/2
14	8747804-24	Hex Head Screw 1/4-20 x 1-1/2
15	5320880-69	Spacer
16	5320481-60	Idler Assembly (Includes Key No. 17)
17	5320885-76	Idler Spacer
18	5320885-17	Shoulder Bolt 5/16-18 x 1-3/8
19	5320885-16	Idler Pulley
20	5320878-77	Selector Knob
21	5327518-09	Selector Assembly (Left)
22	5327518-10	Selector Assembly (Right)

Key No.	Part No.	Description
23	5320881-18	Felt Washer
24	5320880-80	Dust Cover
25	5320677-25	Washer
26	5320884-46	Wheel Bushing
27	5328506-90	Wheel & Tire Assembly
28	5320521-60	Washer
29	5320851-79	Retainer Clip
30	5320774-00	Hubcap
31	8120000-58	E-Ring
32	5321370-54	Pinion
33	8736804-00	Locknut 1/4-20
34	5327005-37	Drive Shaft
35	5320880-82	Driven Pulley
37	5327014-77	Push Fastener
--	5328520-00	"Clean Under" Decal



Key No.	Part No.	Description
1	5321325-70	Control Bar
2	5321414-32	Upper Handle
3	5321254-21	Lower Handle
4	5321320-01	Rope Guide
5	8736804-00	Locknut 1/4-20
6	5321319-59	Handle Bolt
7	5320664-26	Cable Tie
8	5320856-92	Machine Screw 1/4-20 x 2-1/8
9	5328514-62	Throttle Control
10	5320857-23	Washer
11	5321308-61	Engine Zone Control Cable
12	5327027-34	Drive Control Cable
13	5327500-29	Pan Head Machine Screw #10-24 x 2
14	5321286-38	Wing Nut
15	5320517-93	Hairpin Cotter
16	5320691-80	Locknut #10-24
17	8736804-00	Keys Locknut 1/4-20
18	5321253-78	Discharge Baffle
19	5321388-65	Back Plate
20	5321388-66	Side Baffle
21	5321362-33	Rear Skirt
23	5320481-38	Rear Door Assembly Kit
24	8736806-00	Locknut 3/8-16
25	5321388-68	Handle Bracket Assembly (Left)
26	5321388-67	Handle Bracket Assembly (Right)
27	5320551-87	Screw 5/16-18 x 3/4
28	5320863-44	Hex Head Self-tapping Screw #10-24 x 1/2
29	5321399-01	Wheel Adjusting Bracket
30	5320849-20	Spacer
31	5321397-28	Muffler Guard
32	5321251-68	Selector Spring
33	5320878-77	Selector Knob
34	5321251-72	Axle Arm Assembly
35	5320623-35	Belleville Washer
36	5320849-21	Shoulder Bolt 3/8-16
37	5328509-57	Wheel & Tire Assembly
38	5320521-60	Washer

Key No.	Part No.	Description
39	5320851-79	Retainer Clip
40	5320774-00	Hubcap
41	5320886-52	Hinge Screw
42	5320539-98	Flat Washer
43	5320554-83	Hex Tapping Screw 1/4-20 x 1/2
44	5321250-35	Rear Baffle
45	5328509-99	Hex Head Thread Rolling Screw 3/8-16 x 2
46	5321073-39	Danger Decal
48	5328509-88	Engine Spacer (Includes Key #49)
49	5328509-87	Engine Bushing
50	5320812-83	Thread Rolling Screw #10-24 x .38
51	5321414-78	Front Baffle
52	5327022-59	Housing Assembly (Incl. Ref. #46)
53	5328510-84	Hex Head Bolt 3/8-24 x 1-3/8 Grd. 8
54	5328502-63	Helical Lock Washer
55	5328510-74	Hardened Washer
56	5328504-72	20" Blade
57	5328515-14	Blade Adapter
64	5322131-46	Cable Clamp
65	5320838-16	Screw #10 x 5/8
66	5320879-30	Cable Clip*
67	5327003-71	Grass Bag
68	5321334-13	Catcher Frame
70	-----	Engine - Briggs/Stratton Model No. 96982*
72	5321284-15	Pop Rivet
73	5321297-14	Handle Grip
--	5328010-36	Danish Importer Decal
--	5327010-07	Operator's Manual (Scand.)
--	5327010-06	Operator's Manual (Euro.)
--	5321414-28	Housing Stripe Decal
--	5328001-97	Noise Level Decal
--	5321413-36	Logo Decal
--	5327006-96	Warning Decal (Multi.)

*These parts must be purchased through an authorized Briggs and Stratton dealer.