




Prod.nr.: 954 05 95-01  
 Engine: B&S 95902 Type: 3117 Trim: 02

## SPARE PARTS

107 25 13-64



\* These parts must be purchased through an authorized Briggs & Stratton dealer.

Key No.	Part No.	Description	Key No.	Part No.	Description
1	5320869-02	Control Bar	27	5321320-10	Flange Locknut 3/8-16
2	5321320-01	Rope Guide	28	8747604-12	Hex Head Bolt 1/4-20 x 3/4
3	5327500-97	Hex Washer Head Self-tapping Screw #10-24 x 1/2	30	5328509-98	Hex Head Thread Rolling Screw 3/8-16 x 1
4	5321254-63	Lower Handle	33	5321354-11	Housing
5		Cable Clamp (Engine)*	34	5328509-77	Blade Adapter
6	5320636-01	Locknut 1/4-20	35	5328509-72	Blade 20"
7	5321254-64	Upper Handle	36	5328510-74	Washer (Hardened)
8	5328518-09	Engine Zone Control Cable <i>5321308-61</i>	37	5328502-63	Helical Lock Washer
9	8743504-24	Hex Head Bolt 1/4-20 x 1-1/2	38	5328510-84	Hex Head Machine Screw 3/8-24 x 1-3/8 Gr. 8
10	5321251-62	Up-Stop Bracket	39		Engine, Briggs & Stratton* Model No. 95902, Type No. 3117-02
11	5320664-26	Wire Tie	40	5321320-04	Hex Nut 1/4-20
12	8747806-16	Hex Head Bolt 3/8-16 x 1	41	5321319-22	Throttle Cable STD
13	5321253-70	Front Baffle	42	8747804-44	Machine Screw 1/4-20 x 2.12
14	5327512-28	Rear Skirt	43		Flat Washer
15	5320812-76	Self-tapping Screw #10-24 x 1/2	44	5321252-07	Skirt Bracket
16	8735104-00	Nut, Keps	45	5327515-92	Locknut 5/8-16
17	5321250-78	Engine Washer	46	5320838-16	Screw, #10 x 5/8
18		Flat Washer	47	5328504-72	Cable Clip, Throttle
19	5327520-52	Discharge Guard	--	5328001-97	Decal Noise Level
20	5320676-09	Shoulder Bolt	--	5328006-39	Decal Warning Var. 01
21	5328000-60	Wheel Assembly 7.00 x 1.50			
22	5321366-24	Spacer Washer			
23	5321073-39	Danger Decal			
24	8191320-12	Washer			
26	7341172-01	Washer			