


BOM OF TDS60A(Old model:TL60A1



Updated date: 14st Dec,2010;

Updated items: 12a ,87a,77a; cancel the no.,and
replace them with 95,96,97 accordingly.

Pos. No	Part code	Part name
1	930301	Handle cover
2	930201a	Handle
3	930202	screw M6×40
4	930203	self-lock nut
5	930901	Clutch Label
6	930001aR1007	Clutch lever
7	930902	clutch Cable
8	930204	flat washer ø6
9	930205R1007	throttle lever assy.
10	930906	Throttle label
11	930907	throttle Cable
12	930206	Flat washer ø8.5×ø17×2
13	930207	fixing plate
14	930208	flange nut M8
15	930209	washer
16	930210	Split Pin
17	930002	Knob cover
18	930211	lock lever
19	930271	flange screwM8×35
20	930908	engine
21	930213	flange screwM6×14
22	930214	engine base
23	930215	self-lock nutM8
24	930272	flange screwM8×60
25	930217R5003	upper cover-2
26	930218	Spring washerø8
27	930219	screwM8×20
28	930220	flat washerø8
29	930221	drive pulley
30	930222	screwM8×35
31	930223	woodruff key4×16
32	930501	Return spring
33	930801	v-belt Z-729
34	930224	flat washerø10
35	930225	spring washerø10
36	930226	screw3/8"-24UNF×25mm
37	930227	tension lever
38	930228	spacer_tension lever
39	930229R5003	front cover
40	930230	flange screwM5×8
41	930502	spring_front wheel
42	930231	self-lock nutM10
43	930232	flat washerø10
44	930233R5003	Frame
45	930234R5003	guard
46	930235	screwM10×70
47	930236R5003	wheel frame
48	930237	shaft_wheel
49	930802	wheel
50	930238	disc
51	930239	pin ø8

52	930240	spring washerø6
53	930241	screw M6×16
54	930242	left tiller
55	930243	right tiller
56	930905	warning label
57	930803	oil seal ø20×ø32×6
58	930101	left gearcase
59	930601	ball bearing6004
60	930244	tiller shaft
61	930245	woodruff key 5×19
62	930602	taper bearing 30203
63	930102	right gearcase
64	930246	inner hexagonal head screw M8×25
65	930247	Oil Plug G1/8×8mm
66	930248	aluminum washer ø10×ø16×1
67	930249	inner hexagonal head screw M6×25
68	930250	sawtooth gasket ø6
69	930251	worm wheel
70	930252	shaft ring ø20
71	930253	flat washer ø20.5×ø35×0.3
72	930254	screw M8×30
73	930255	oil seal cover
74	930256	clip
75	930257	pin ø8
76	930258	bush
77	930259	flat washer ø8.5×ø30×3
78	930260	spacer_tension pulley
79	930261	driven pulley
80	930003	tension pulley
81	930262R5003	upper cover-1
82	930263	draw bar
83	930804	strape
84	930264	connecting tube
85	930265	adjusting screw
86	930266	screw M8×70
87	930603	ball bearing 6204-2RS
88	930267	Worm shaft
89	930268	pin-plate
90	930269	inner hexagonal head screw M8×38
91	930270	sawtooth gasket ø8
92	930273	self-lock nut M5
93	930274	muffler outlet guard
94	930275	flat washer ø5
95	930279	screw M6×40
96	930280	washer 14.2×20×0.4
97	930281	flat washer 8.5×27×1.5
101	904015R1007	lock hook trigger
102	930276	bush
103	930277	Lock lever
104	930503	torsional spring
105	930278	spring pin(Φ3X16)