


ILLUSTRATION SHOWS TYPICAL PARTS ONLY.
ORDER BY PART NUMBER. PARTS NOT ILLUSTRATED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
1	772070		Transmission Cover
2	780142		Needle Bearing
3	770061A		Transmission Case
4	776134		Countershaft
8	792071		Shifter Key
9	784216		Shift Collar
10	784224		Shift Rod & Fork
11	778109A		Bevel Gear (Incl. 15-tooth gear)
12	778113A		Input Bevel Pinion
19	786048		Sprocket (8 teeth)
20	792077A		Steel Ball 5/16"
21	792078		Set Screw, 3/8-16 x 3/8"
22	792079	500-502	Spring Page 2 of 2
25	792073A	Peerless	Screw, 1/4-20 x 1-1/4"
26	792072		Retaining Ring
27	792035		Retaining Ring
28	788040		Retaining Ring
29	780072		Thrust Washer
34	780105A		Flanged Bushing
36	790003		Brake Disk
37	790007		Brake Pad Plate
38	799021		Brake Pad (pkg of 2)
39	786026		Dowel Pin
40	792076A		Flat Washer 5/16"
41	790010		Brake Lever
43	792075		Locknut 5/16-24
44	790025		Brake Pad Holder
50	778107		Spur Gear (30 teeth)
51	778106		Spur Gear (25 teeth)
52	778105		Spur Gear (20 teeth)
57	778110		Spur Gear (20 teeth)
58	778111		Spur Gear (25 teeth)
59	778112		Spur Gear (30 teeth)
66	776142		Input Shaft
67	776141		Brake Shaft
72	792074		Threaded Plug
81	786062A		Roller Chain (No. 41 chain, 22 links)
82	786061		Sprocket (10 teeth)
83	786060		Sprocket (14 teeth)
90	788067B		Grease (32 oz. bottle Bentonite grease)
144	792084		Roll Pin
146	786064		Knob Assembly (Incl. 144)