


p601.2\_pg1 601-601-018 / Transaxle pg1

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

VIEW 1 of 2











## Part List

p601.2\_pg1 601-601-018 / Transaxle pg1

REF #	ITEM #	DESCRIPTION	QTY	REMARK
1	772042	Transaxle Cover		
2	780061	Bronze Bearing		
2A	780063	Needle Bearing		
3	770063	Transaxle Case (Incl. 2, 35 & 78)		
4	786080	Countershaft Sleeve (Incl. 2 of 78A)		
7	778150	Spur Gear (11 teeth)		
8	792045	Woodruff Key		
10	784004	Shift Fork		
11	778148A	Bevel Gear (42 & 16 teeth) (Incl. 176)		
12	778149	Input Pinion		
13	778067	Bevel Gear		
14	778068	Bevel Pinion		
15	778175	Differential Gear (Incl. 2 of 120)		
17	786034	Drive Pin		
20	792004	Steel Ball		
22	792003	Spring		
25	792036	Screw, 1/4-20 x 1-1/4"		
25A	792007	Screw, 1/4-20 x 3/4"		
26	788038	Snap Ring		
26A	792017	Snap Ring		
27	792035	Retainer Ring		
28	788040	Retainer Ring		
30	780065	Thrust Washer		
31	780001	Thrust Washer		
35	780059	Bronze Bearing		
36	790009	Brake Disk		
37	790007	Brake Pad Plate		
38	799021	Brake Pad (pkg of 2)		
39	786026	Dowel Pin		
40	792076A	Flat washer		
41	790004	Brake Lever		
42	792073A	Screw, 1/4-20 x 1-1/4"		
42A	792085A	Screw, 1/4-20 x 2-1/4"		
43	792075	Locknut		
44	790025	Brake Pad Holder		
45	786066	Spacer		
47	774221	Axle (9-15/64" long)		
48	774220	Axle (17-55/64" long)		
49	778059	Shifting Gear (1st & Rev.)		
50	778058	Shifting Gear (2nd & 3rd)		
56	778142	Countershaft Gear (25 teeth)		
57	778141	Countershaft Gear (34 teeth)		
58	778140	Countershaft Drive Gear (39 teeth)		
63	786079	Spacer (.861" long)		
63A	786078	Spacer (1.227" long)		
66	776200	Input Shaft		
67	776138	Shifter & Brake Shaft		
78	780086A	Needle Bearing		
78A	780066	Bronze Bearing		
85	792039	Pipe Plug, 1/8"		
87	788009	Oil Seal		
88	780093	Ball Bearing		
97	780072	Thrust Washer		
117	780140	Needle Bearing		
120	780064	Bronze Bearing		
120A	780060	Bronze Bearing		
120B	780062	Bronze Bearing		

123	792040	Roll Pin		
124	788033A	Case & Cover Gasket		
124A	788003A	Shift Lever Housing Gasket		
133	786033	Center Plate (Incl. 120A & 120B)		
136	782036A	Axle Housing (Incl. 117 & 157)		
138	782043	Axle Housing (Incl. 117 & 157)		
142	792016	Snap Ring		
143	792001	Square Cut Ring		
144	792049	Drive Pin		
145	784284	Shift Lever		
146	784094	Shift Lever Keeper		
147	784088	Shift Lever Housing		
148	784083	Shift Rod		
148A	784079	Shift Rod		(1st/Rev) Incl. 10,20,22,26A& 148
149	784085	Shift Rod		
149A	784084	Shift Rod		(2nd/3rd) Incl. 10,20,22,26A& 149
153	784087	Shifter Stop		
155	792037	Screw, 5/16-18 x 1"		
157	788042	Oil Seal		
157A	788043	Oil Seal		
157B	788035A	Oil Seal		
159	776057	Reverse Idler Shaft		
160	786036	Reverse Idler Spacer		
161	778064	Reverse Idler Gear (13 teeth)		
176	776190A	Spline Gear		Used on early production
180	730229A	Gear Oil SAE 80W90		

p601.2\_pg2 601-601-018 / Transaxle pg2

<b>47</b> 	<b>VIEW 2 of 2</b>	<b>48</b> 
<b>47A</b> 		<b>48A</b> 
<b>47B</b> 		<b>48B</b> 
<b>47C</b> 		<b>48C</b> 

## Part List

*p601.2\_pg2 601-601-018 / Transaxle pg2*

REF #	ITEM #	DESCRIPTION	QTY	REMARK
36	790009	Brake Disk		
42A	792085A	Screw, 1/4-20 x 2-1/4"		
47	774221	Axle (9-15/64" long)		
48	774220	Axle (17-55/64" long)		