


p700000.2 700-700-056 / Transmission



Part List

p700000.2 700-700-056 / Transmission

REF #	ITEM #	DESCRIPTION	QTY	REMARK
1	772099A	Transmission Cover		
2	780086A	Needle Bearing		
2A	780142	Needle Bearing		
3	770090A	Transmission Case		
4	776134	Countershaft		
8	792089A	Shifter Key		
9	784266	Shift Collar		
10	784357	Shift Rod & Fork		
11	778154	Bevel Gear (42 teeth-steel)		
12	778176	Input Bevel Pinion		
20	792077A	Steel Ball, 5/16" dia.		
21	792078	Set Screw, 3/8-16 x 3/8"		
22	792079	Spring		
24	780071	Thrust Bearing		
25	792073A	Screw, 1/4-20 x 1-1/4"		
27	792035	Retaining Ring		
28	788040	Retaining Ring		
29	780072	Thrust Washer		
30	780108	Thrust Washer		
30A	780108	Thrust Washer		
31	780065	Thrust Washer		
32	792001	"O" Ring		
34	780105A	Flanged Bushing		
49	778125	Spur Gear (35 teeth)		
50	778239A	Spur Gear (32 teeth-steel)		
51	778124A	Spur Gear (30 teeth)		
52	778250	Spur Gear (27 teeth)		
53	778123A	Spur Gear (25 teeth)		
56	778136	Spur Gear (15 teeth-steel)		
57	778240	Spur Gear (18 teeth-steel)		
58	778126A	Spur Gear (20 teeth)		
59	778249	Spur Gear (23 teeth)		
60	778127A	Spur Gear (25 teeth)		
65	780139	Thrust Washer (stepped)		
66	776135	Input Shaft (3-11/16" long)		
67	776341	Brake Shaft (8.594" long)		
71	788069	Square Cut Seal		
72	792074	Threaded Plug		
81	786081	Roller Chain (No. 41 chain, 24 links)		
82	786082	Sprocket (9 teeth)		
83	786083	Sprocket (18 teeth)		
89	780092	Ball Bearing		
90	788067B	Grease		32 oz. bottle Bentonite grease
150	510334	Gasket Eliminator (Loctite #515)		