


ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
1	772083A		Transmission Cover
2	780086A		Needle Bearing
2A	780086A		Needle Bearing
3	770061A		Transmission Case
4	776134		Countershaft
8	792089A		Shifter Key
9	784266		Shift Collar
10	784270		Shift Rod & Fork
11	778137A		Bevel Gear (42 teeth)
12	778113A		Input Bevel Pinion
19	786049		Sprocket (8 teeth)
20	792077A		Steel Ball, 5/16" dia.
21	792078	700-700-017A	Set Screw, 3/8-16 x 3/8"
22	792079	Peerless	Spring
25	792073A		Screw, 1/4-20 x 1-1/4"
26	792072		Retaining Ring
27	792035		Retaining Ring
28	788040		Retaining Ring
29	780072		Thrust Washer
30A	780108		Thrust Washer
30	780108		Thrust Washer
32	792001		"O" Ring
33	788074		"O" Ring
34	780105A		Flanged Bushing
49	778146A		Spur Gear (37 teeth)
50	778124A		Spur Gear (30 teeth)
51	778273		Spur Gear (19 teeth-steel)
56	778145		Spur Gear (12 teeth-steel)
57	778126A		Spur Gear (20 teeth)
58	778163		Spur Gear (31 teeth)
63	786071		Countershaft Spacer (3/8" long)
64	786072		Output Shaft Spacer (3/8" long)
65	780109		Thrust Washer (flat)
66	776203		Input Shaft (5-41/64" long)
67	776162		Brake Shaft (8-13/16" long)
71	788069		Square Cut Seal
72	792074		Threaded Plug
81	786062A		Roller Chain (No. 41 chain, 22 links)
82	786061		Sprocket (10 teeth)
83	786060		Sprocket (14 teeth)
90	788067B		Grease (32 oz. bottle Bentonite grease)
124	788054		Gasket
150	510334		Gasket Eliminator (Loctite #515)