

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
1	772099A		Transmission Cover
2A	780142		Needle Bearing
2	780086A		Needle Bearing
3	770090A		Transmission Case
4	776134		Countershaft
8	792089A		Shifter Key
9	784266		Shift Collar
10	784357		Shift Rod & Fork
11	778154		Bevel Gear (42 teeth-steel)
12	778176		Input Bevel Pinion
20	792077A		Steel Ball, 5/16" dia.
21	792078		Set Screw, 3/8-16 x 3/8"
22	792079	700-700-042	Spring Page 2 of 2
24	780071	Peerless	Thrust Bearing
25	792073A		Screw, 1/4-20 x 1-1/4"
27	792035		Retaining Ring
28	788040		Retaining Ring
29	780072		Thrust Washer
30	780108		Thrust Washer
31	780065		Thrust Washer
32	792001		"O" Ring
34	780105A		Flanged Bushing
49	778146A		Spur Gear (37 teeth)
50	778125		Spur Gear (35 teeth)
51	778239A		Spur Gear (32 teeth-steel)
52	778124A		Spur Gear (30 teeth)
53	778250		Spur Gear (27 teeth)
56	778145		Spur Gear (12 teeth-steel)
57	778151		Spur Gear (15 teeth)
58	778240		Spur Gear (18 teeth-steel)
59	778126A		Spur Gear (20 teeth)
60	778249		Spur Gear (23 teeth)
65	780139		Thrust Washer (stepped)
66	776135		Input Shaft (3-11/16" long)
67	776289A		Brake Shaft (8-13/16" long)
71	788069		Square Cut Seal
72	792074		Threaded Plug
81	786081		Roller Chain (No. 41 chain, 24 links)
82	786082		Sprocket (9 teeth)
83	786083		Sprocket (18 teeth)
89	780092		Ball Bearing
90	788067B		Grease (32 oz. bottle Bentonite grease)
150	510334		Gasket Eliminator (Loctite #515)