


136



Ref #	Part Number	Qty	Description
1	772081		Transmission Cover
2	780086A		Needle Bearing
3	770061A		Transmission Case
4	776134		Countershaft
8	792089A		Shifter Key
9	784329		Shift Collar
10	784314		Shift Rod & Fork
11	778137A		Bevel Gear (42 teeth)
12	778113A		Input Bevel Pinion
19	786047		Sprocket (8 teeth)
20	792004		Steel Ball, 3/16" dia.
21	792068		Set Screw, 1/4-20 x 1/2"
22	792003		Spring
25	792073A	700-741A Peerless	Screw, 1/4-20 x 1-1/4"
26	792072		Retaining Ring
27	792035		Retaining Ring
28	788040		Retaining Ring
29	780072		Thrust Washer
30	780108		Thrust Washer
32	792001		"O" Ring
34	780105A		Flanged Bushing
36	790003		Brake Disk
37	790007		Brake Pad Plate
38	799021		Brake Pad (pkg of 2)
39	786026		Dowel Pin
40	792076A		Flat Washer, 5/16"
41	790013		Brake Lever
42	792073A		Screw, 1/4-20 x 1-1/4"
43	792075		Lock Nut, 5/16-24
44	790025		Brake Pad Holder
46	786086		Brake Lever Bracket
49	778124A		Spur Gear (30 teeth)
56	778126A		Spur Gear (20 teeth)
63A	786088		Spacer (.180 long)
63B	786089		Spacer (1-1/2" long)
64A	786090		Spacer (1.532" long)
65	780109		Thrust Washer
66	776135		Input Shaft (3-11/16" long)
67	776217		Brake Shaft (8-13/16" long)
81	786081		Roller Chain (No. 41 chain, 24 links)
82	786082		Sprocket (9 teeth)
83	786083		Sprocket (18 teeth)
90	788067B		Grease (32 oz. bottle Bentonite greas e)
127	784313		Shift Lever Cap
128	792059		Screw, 1/4-20 x 3/4"
129	784315		Shifter Guide
130	32426		Spacer
144	792049		Drive Pin
145	784312		Shift Lever
150	510334		Gasket Eliminator (Loctite #515)