



JOIST

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

MODEL and SERIAL
NUMBERS HERE





Ref #	Part Number	Qty	Description
1	772083A		Transmission Cover
2A	780142		Needle Bearing
2	780086A		Needle Bearing
3	770061A		Transmission Case
4	776134		Countershaft
8	792089A		Key
9	784266		Collar
10	784267		Shift Rod & Fork
11	778154		Bevel Gear (42 teeth-steel)
12	778153		Input Bevel Pinion (steel)
20	792077A		Steel Ball, 5/16"
21	792078		Set Screw, 3/8-16 x 3/8"
22	792079	700-787	Spring Page 2 of 2
25	792073A	Peerless	Screw, 1/4-20 x 1-1/4"
27	792035		Retaining Ring
28	788040		Retaining Ring
29	780072		Thrust Race
30A	780108		Thrust Washer (1/16" thick)
30	780108		Thrust Washer (1/16" thick)
32	792001		"O" Ring
34	780105A		Flange Bushing
49	778146A		Spur Gear (37 teeth)
50	778125		Spur Gear (35 teeth)
51	778124A		Spur Gear (30 teeth)
52	778123A		Spur Gear (25 teeth)
56	778145		Spur Gear (12 teeth)
57	778151		Spur Gear (15 teeth)
58	778126A		Spur Gear (20 teeth)
59	778127A		Spur Gear (25 teeth)
63	786071		Spacer (3/4" ID x 1-1/8" OD x 3/8" thick)
64	786072		Output Shaft Spacer
65	780139		Washer
66	776135		Input Shaft (3-11/16" long)
67	776217		Output & Brake Shaft (8-13/16" long) (Shaft has four keyways and replaces shafts with two keyways. Use four keys)
71	788069		Square Cut Seal
72	792074		Threaded Plug
81	786081		Roller Chain (No. 41 chain, 24 links)
82	786082		Sprocket (9 teeth)
83	786083		Sprocket (18 teeth)
86	792083		Washer (Use as required)
90	788067B		Grease (32 oz. bottle Bentonite grease)
150	510334		Gasket Eliminator (Loctite No. 515)
178	786108		Coupler
179	776230		Connector Shaft (4-63/64" long)
179	776231		Connector Shaft (7-39/64" long)