



MODEL and SERIAL
NUMBERS HERE



Ref #	Part Number	Qty	Description
1	772089		Transaxle Cover
2	780086A		Needle Bearing
3	770075		Transaxle Case
4	776218		Countershaft
5	776219A		Output Shaft & Pinion
6	778139		Output Gear
7	778136		Spur Gear
8	792108		Key
9	784216		Shift Collar
10	784330		Shift Rod & Fork
11	778137A		Bevel Gear (42 teeth)
12	778113A		Input Bevel Pinion (14 teeth)
13	778221		Bevel Gear (16 teeth)
14	778068	900-900-0085 Peerless	Bevel Pinion Gear (16 teeth)
15	778165		Ring Gear
16	786101		Bearing Block
17	786040		Drive Pin
18	786102		Neutral Spacer
20	792077A		Steel Ball, 5/16" dia.
21	792078		Set Screw, 3/8-16 x 3/8"
22	792079		Spring
23	788061		Seal Ring
25	792073A		Screw, 1/4-20 x 1-1/4"
26	792125		Retaining Ring (pkg of 2)
27	792035		Retaining Ring
28	788040		Retaining Ring
29	780072		Thrust Washer
30	780108		Thrust Washer
31	780001		Washer
32	792001		"O" Ring
33	788051A		Square Cut Ring
34	780105A		Flanged Bushing
35	780118A		Flanged Bushing
35A	780129		Flanged Bushing
36	790003		Brake Disk
37	790007		Brake Pad Plate
38	799021		Brake Pad (pkg of 2)
39	786026		Dowel Pin
40	792076A		Flat Washer
41	790036		Brake Lever
42	792073A		Screw, 1/4-20 x 1-1/4"
42A	792073A		Screw, 1/4-20 x 1-1/4"
43	792075		Lock Nut, 5/16-24
44	790025		Brake Pad Holder
46	786086		Brake Lever Bracket
47	774736		Axle (12-1/32" long)
48	774737		Axle (14-29/32" long)
49	778125		Spur Gear (35 teeth)
50	778123A		Spur Gear (25 teeth)
56	778151		Spur Gear (15 teeth)
57	778127A		Spur Gear (25 teeth)
63	786071		Countershaft Spacer
64	786072		Brake Shaft Spacer
65	780139		Thrust Washer (stepped)
66	776135		Input Shaft (3-11/16" long)
67	776220		Brake Shaft



Ref #	Part Number	Qty	Description
72	792074		Threaded Plug
81	786081		Roller Chain (No. 41 chain, 24 links)
82	786082		Sprocket (9 teeth)
83	786107		Sprocket (18 teeth)
90	788067B		Grease (32 oz. bottle Bentonite greas e)