


MODEL 20705X51D

REPAIR PARTS






MODEL 20705X51D

REPAIR PARTS

| KEY NO. | DESCRIPTION | PART NO. | KEY NO. | DESCRIPTION | PART NO. |
|---------|----------------------------|------------|---------|-----------------------------|------------|
| 1 | Housing | _____ | 33 | Axle | 671931 |
| 2 | Engine * | * | 34 | Cover, Axle (Black) | 671948 |
| 3 | Pulley, Engine | 71434 | 35 | Nut, Flange | 15x68 |
| 4 | Pin, Spring | 32x64 | 36 | Nut, Hex | 15x102 |
| 6 | Cover, Belt (Black) | 671928 | 37 | Washer | 17x38 |
| 7 | Screw | 26x279 | 38 | Screw | 4x21 |
| 8 | Adjuster, Left Height | 672605 | 39 | Cap, Hub | 43615 |
| 9 | Bolt, Shoulder | 9x50 | 40 | Washer | 17x169 |
| 10 | Pulley | 71779 | 41 | Nut, Flange | 15x84 |
| 11 | Spacer | 71788 | 42 | Wheel, Drive | 71133 |
| 12 | Bracket, Idler Support | 672772 Z | 43 | Washer | 17x120 |
| 13 | Pulley, Idler | 71778 | 44 | Cover, Dust | 71780 |
| 14 | Bearing | 71793 | 45 | Washer, Belleville | 17x137 |
| 15 | Nut, Push | 28x49 | 46 | Washer | 17x124 |
| 16 | Bracket, Left Handle | 672591E700 | 47 | Bolt | 1x153 |
| 17 | Bracket, Cable | 671934 | 48 | Blade | 672763E701 |
| 18 | Nut, Hex | 15x43 | 49 | Adapter, Blade | 672503 |
| 19 | Spacer | 71789 | 50 | Adjuster, Right Frt. Height | 672602 |
| 20 | Arm, Idler | 671936 z | 53 | Bolt, Engine | 25x6 |
| 21 | Bolt, Carriage | 2x53 | 55 | Washer | 17x146 |
| 22 | Bolt, Shoulder | 1x81 | 56 | Nut, Flange | 15x88 |
| 23 | E-Ring | 11x16 | 57 | Rod, Pivot | 215x17 Z |
| 24 | Gear, Pinion | 71792 | 58 | Door, Rear (Black) | 672610 |
| 25 | Bolt | 1x85 | 59 | Spring | 166x44 |
| 26 | Washer | 17x186 | 60 | Deflector, Rear | 671970 |
| 27 | Adjuster, Left Frt. Height | 672603 | 61 | Wheel, Rear | 71132 |
| 28 | Belt | 37x84 | 63 | Bracket, Right Handle | 672590E700 |
| 29 | Pulley, Axle | 71791 | 64 | Adjuster, Right Height | 672604 |
| 30 | Screw | 26x263 | 65 | Screw | 26x245 |
| 31 | Pin, Hair | 31x9 | 72 | Guard, Rear | 671990 |
| 32 | Pin, Spring | 43629 | -- | Instruction Book | F-99449 |

MODEL 20705X51D

REPAIR PARTS



| KEY NO. | DESCRIPTION | PART NO. |
|---------|-----------------------|------------|
| 1 | Engine * | |
| 1 | Handle, Upper (Black) | 672665E701 |
| 2 | Handle, Lower (Black) | 671940E701 |
| 3 | Bolt | 26x286 |
| 4 | Control, Drive | 672580 |
| 5 | Locknut | 15x116 |
| 6 | Cable, Stop | 672664 |
| 7 | Throttle Control | 672144 |
| 8 | Engine Stop Lever | 672570E700 |
| 9 | Screw | 25x14 |
| 11 | Fastener, Cable | 71372 |
| 12 | Bolt | 2x77 |
| 13 | Knob | 71294 |
| 14 | Screw | 26x268 |
| 15 | Clamp | 42294 |
| 16 | Guide, Rope | 43956 |

| KEY NO. | DESCRIPTION | PART NO. |
|---------|-----------------------|------------|
| 17 | Cap | 91488 |
| 18 | Nut | 91489 |
| 19 | Bolt | 3x136 |
| 20 | Cover, Ignition | 671916 |
| 21 | Switch Ignition & Key | 776011 |
| 22 | Charger, Battery | 671991 |
| 23 | Harness, Wiring | 250x72 |
| 24 | Battery | 776014 |
| 25 | Case, Battery | 776013 |
| 26 | Bracket, Battery | 671959E701 |
| 27 | Key, Ignition | 20729 |
| 28 | Frame, Top | 71592 |
| 29 | Frame Assembly | 672614 |
| 30 | Bag, Cloth | 672069 |
| 31 | Bracket, Stop Lever | 43628 BC |