


MODEL 20745x194C

REPAIR PARTS



MODEL 20745x194C


REPAIR PARTS

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Housing	776157	39	Hub Cap - Optional	672122
2	Engine *	-----	40	Washer	17x169
3	Pulley, Engine	71434	41	Nut, Flange	15x84
4	Pin, Spring	32x64	42	Wheel, Drive	71133
6	Cover, Belt (Black)	671928	43	Washer	17x120
7	Screw	26x279	44	Cover, Dust	71780
8	Adjuster, Left Rear Height	672607	45	Washer, Belleville	17x137
9	Bolt, Shoulder	9x50	46	Washer	17x124
10	Pulley	71779	47	Bolt	1x153
11	Spacer	71788	48	Blade	672763E701
12	Bracket, Idler Support	672772 Z	49	Adapter, Blade	672503
13	Pulley, Idler	71778	50	Adjuster, Right Frt Height	672602
14	Bearing	71793	51	Bolt, Carriage	2x16
15	Nut, Push	28x49	52	Screw	26x221
16	Bracket, Left Handle	1101245E700	53	Bolt, Engine	25x6
17	Bracket, Cable	671934	54	Knob	672449
18	Nut, Hex	15x43	55	Washer	17x146
19	Spacer	71789	56	Nut, Flange	15x88
20	Arm, Idler	671936	57	Rod, Pivot	215x17 Z
21	Bolt, Carriage	2x53	58	Door, Rear (Black)	672610
22	Bolt, Shoulder	1x81	59	Spring	166x44
23	E-Ring	11x16	60	Deflector, Rear	671970
24	Gear, Pinion	71792	61	Wheel, Rear	71841
25	Bolt	1x85	62	Washer	17x91
26	Washer	17x186	63	Bracket, Right Handle	1101244E700
27	Adjuster, Left Frt Height	672603	64	Adjuster, Right Rear Hight	672606
28	Belt	37x99	65	Screw	26x245
29	Pulley, Axle	71791	66	Wingnut	71495
30	Screw	26x263	67	Retainer, Push	28x64
31	Pin, Hair	31x9	68	Bezel (Black)	671926
32	Pin, Spring	43629	69	Pin, Pivot	215x18Z
33	Axle	671931	70	Deflector, Chute (Black)	671927
34	Cover, Axle (Black)	671948	71	Push On Cap	28x42
35	Nut, Flange	15x68	72	Brace	672737E700
36	Nut, Hex	15x102	73	Bolt, Carriage	2x81
37	Washer	17x38	74	Knob	71495
38	Screw	4x21	--	Instruction Book	F-010404L


* Parts are available from an Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

MODEL 20745x194C

REPAIR PARTS



KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Handle, Upper (Black)	671918E701	16	Guide, Rope	71530
2	Handle, Lower (Black)	672875E701	17	Cap	91488
3	Bolt	25x14	18	Nut	91489
4	Control, Drive	1101420	19	Bolt	3x136
5	Locknut	15x116	20	Cover, Ignition	671916
6	Cable, Stop	1101367	21	Switch Ignition & Key	776011
7	Fastener, Single Cable	1101352	22	Charger, Battery	671992
8	Lever, Stop	672878E701	23	Harness, Wiring	776012
9	Bracket, Stop Lever	43628 BC	24	Battery	776014
10	Screw	26x220	25	Case, Battery	776013
11	Fastener, Cable	71372	26	Bracket, Battery	671959
12	Bolt	2x77	27	Key, Ignition	672220
13	Knob	71294			



KEY NO.	DESCRIPTION	PART NO.
1	Frame, Top	71592
2	Frame Assembly	672905
3	Bag, Cloth - Black	1101003
--	Complete Service Replacement Kit *	24201

* Order from your nearest Central Parts Distributor.