


MODEL 22605x50C


REPAIR PARTS



1	Engine *	-----	13	Washer	17x124
2	Housing	776049	14	Bolt, Hex	1x153
3	Height Adjuster, Left Rear	672641	15	Blade	672735E701
4	Knob	71495	16	Adapter, Blade	672503
5	Wheel and Tire, Rear	71132	17	Height Adjuster, Right Front	672642
6	Locknut, Flange	15x84	18	Height Adjuster, Right Rear	672640
7	Bolt, Carriage	2x81	19	Guard, Rear	672738
9	Bolt, Engine	25x11	20	Screw	26x245
10	Nut	15x68	21	Deflector, Chute	672721
11	Height Adjuster, Left Front	672643	22	Push-On Cap	28x42
12	Washer, Belleville	17x137	23	Pin, Pivot	215x11 Z
24	Spring	166x5			
25	Baffle	672744E700			
26	Wheel and Tire, Drive	71133			
27	Pulley	71434			
28	Pin, Spring	32x64			
29	Base, Engine	672671E700			
30	Cover, Belt	1101025			
31	Screw	26x259			
32	Bracket, Idler Support	672751 Z			
33	Bolt	1x81			
34	Screw	26x263			
35	Idler, Backside	672751 Z			
36	Locknut	15x43			
37	Bearing	71793			
38	Spring	166x45			
39	Spacer	71789			
40	Arm, Pivot	672753 Z			
41	Spacer	71788			
42	Pulley, Idler	71779			
43	Bolt, Shoulder	9x50			
44	Belt	37x100			
45	Washer	17x186			
46	Ring, Retainer	11x16			
47	Gear, Pinion	71792			
48	Pulley	71791			
49	Pin, Drive	43629			
50	Pin, Hair	31x9			
51	Axle	672508			
52	Washer	17x169			
53	Cover, Dust	71780			
54	Bolt	1x85			
55	Hub Cap	672122			
56	Plate, Mulcher	672422 Z			
57	Bracket, Left Handle	672335E700			
58	Bracket, Right Handle	672334E700			
59	Screw	26x289			
60	Bolt	1x120			
61	Extension, Rear	672711E700			
64	Screw	26x288			
65	Shield, Debris	1101026E700			
-	Book, Instruction	F-000450L			

MODEL 22605x50C

REPAIR PARTS



1	Handle, Upper (Gray)	71581E724	5	Locknut	15x116	11	Fastener, Cable	71372
2	Handle, Lower (Gray)	71137E724	6	Cable, Stop	672839	12	Bolt	2x77
3	Screw	25x14	8	Lever, Stop	672879E700	13	Knob	71294
4	Control, Drive	672873	10	Bracket, Stop Lever	43628 BC	16	Guide, Rope	71530