



STIGA
196E
SPARE PARTS

Section: VILLA STEERING SEAT

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------|---------------------|---------------|-----|
| | 2812 | 2816 | | | | |
| | 2832 | 2836 | | | | |
| | | 2858 | | | | |
| 1 | 1 | 1 | 1134-1967-01 | Steering wheel+colu | | |
| 2 | 1 | 1 | 9595-0262-00 | .Locating pin | | |
| 3 | 1 | 1 | 9699-0103-02 | .Flat washer | 0.5 mm | |
| 3 | 1 | 1 | 9699-0114-02 | .Flat washer | 1.0 mm | |
| 4 | 1 | 1 | 9595-0262-00 | Locating pin | | |
| 5 | 1 | 1 | 1134-1424-01 | Steering column | | |
| 6 | 2 | 2 | 1134-1901-01 | Bearing | | |
| 8 | 1 | 1 | 1134-1933-01 | Steering pulley | | |
| 9 | 4 | 4 | 1134-0041-01 | Bushing | | |
| 10 | 2 | 2 | 1134-9025-01 | Steering pulley-kit | | |
| 11 | 4 | 4 | 1134-3022-01 | Cable holder | | |
| 12 | 4 | 4 | 9942-1030-16 | Screw | | |
| 13 | 1 | 1 | 1134-9023-01 | Steering wire | | |
| 14 | 5 | 5 | 9747-0831-02 | Lock nut | | |
| 15 | 1 | 1 | 9699-0090-02 | Flat washer | | |
| 16 | 1 | 1 | 1134-1310-01 | Compression spring | | |
| 17 | 5 | 5 | 9959-0816-16 | Screw | | |
| 18 | 4 | 4 | 9739-0831-22 | Nut | | |
| 19 | 1 | 1 | 1134-9024-01 | Bearing | | |
| 20 | 1 | 1 | 1134-0341-01 | Washer | | |
| 21 | 1 | 1 | 9650-0020-04 | Circlip | | |
| 22 | 4 | 4 | 9799-0831-02 | Nut | | |
| 23 | 1 | 1 | 1134-1500-01 | Steering pulley | | |
| 24 | 4 | 4 | 9570-0002-00 | Elbow link | | |
| 25 | 2 | 2 | 1134-1427-01 | Tie rod | | |
| 30 | 1 | 1 | 9959-0825-16 | Screw | | |
| 32 | 1 | 1 | 1134-0022-00 | Control rod | | |
| 33 | 2 | 2 | 9672-0004-02 | Lock washer | | |
| 34 | 1 | 1 | 1134-2163-01 | Rod | | |
| 35 | 1 | 1 | 1134-2166-01 | Spacer | | |
| 42 | 1 | 1 | 1134-3252-02 | Seat bracket-yellow | | |
| 43 | 1 | 1 | 1134-2846-01 | Tube | | |
| 44 | 1 | 1 | 1134-1883-01 | Axle | | |
| 45 | 1 | 1 | 1134-0015-00 | Seat spring | | |
| 48 | 1 | 1 | 1134-1652-01 | Spring shackle | | |
| 49 | 1 | 1 | 1134-0050-00 | Seat rod | | |
| 50 | 1 | 1 | 1134-0493-00 | Spring nut | | |
| 52 | 2 | 2 | 1134-1650-01 | Tie bar | | |
| 53 | 4 | 4 | 9675-0017-02 | Lock washer | | |
| 54 | 2 | 2 | 1134-2961-01 | Seat adapter | | |
| 55 | 2 | 2 | 9898-0820-16 | Screw | | |
| 56 | 4 | 4 | 9988-3616-16 | Screw | | |
| 57 | 2 | 2 | 9699-0062-02 | Flat washer | | |
| 58 | 2 | 2 | 1134-1711-01 | Knob | | |
| 63 | 1 | 1 | 1134-3618-01 | Seat bracket-R.H. | | |
| 64 | 1 | 1 | 1134-3618-02 | Seat bracket-L.H. | | |
| 65 | 1 | 1 | 1134-0800-06 | Seat | | |
| 65 | | | 1134-2541-01 | Seat | Tyskland (DE) | |
| 67 | 1 | 1 | 1134-2454-01 | Shaft | | |
| 68 | 2 | 2 | 9672-0006-02 | Lock washer | | |
| 69 | 1 | 1 | 1134-2847-01 | Shaft | | |