



Section: JB 90-JB 921 CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1121	1129				
1	1	1482-0576-01	Wing nut			
2	1	1482-0582-01	Engine hood			
3	1	1482-0542-01	Hood bracket			
4	1	9942-0620-16	Screw			
40	1	1482-0573-01	Gas cable			
51	1	9997-0625-16	Screw			
52	1	1482-0588-01	Plastic washer			
53	1	1482-0589-01	Gas control lever			
54	4	1482-0570-01	Screw			
55	1	1482-0590-01	Control plate			
56	1	1482-0577-01	Front plate			
58	1	1482-0578-01	Tool box			
59	2	9836-9216-12	Screw			
60	1	1482-0591-01	Foam piece			
61	1	1482-0546-01	Handlebar			
62	2	9997-0620-16	Screw			
63	2	9683-0025-02	Lock washer			
64	1	1482-0540-01	Rod			
65	2	9699-0025-02	Washer			
66	2	9699-0025-02	Washer			
67	2	9997-0620-16	Screw			
68	2	9683-0025-02	Lock washer			
69	2	9699-0025-02	Washer			
70	1	1482-0544-01	Locking handle			
71	1	1482-0548-01	Locking bolt			
72	1	9997-1040-12	Screw			
73	1	1482-0574-01	Grip			
74	1	1482-0541-01	Handle attachment			
75	1	1482-0549-01	Handle bracket			
82	1	9699-0097-02	Flat washer			
84	1	9699-0035-02	Flat washer			
85	1	9747-1031-02	Lock nut			
86	1	9747-1231-02	Lock nut			
92	2	9997-0616-16	Screw			
93	1	1482-0568-01	Dish washer			
93	2	9699-0025-02	Washer			
94	2	9699-0025-02	Washer			
95	2	9683-0025-02	Lock washer			
96	2	9799-0631-02	Nut			
97	3	1482-0579-01	Bracket			
98	1	1482-0539-01	Guard plate			
115	1	9794-5131-02	Nut			
116	1	1482-0537-01	Depht control			
117	1	9987-5119-16	Screw			
118	1	9598-0002-02	Pin lock			
119	1	1482-0041-00	Cotter bolt			
120	1	9598-0002-02	Pin lock			
121	1	1482-0041-00	Cotter bolt			
123	1	1482-0558-01	Spring			
124	1	1482-0555-01	Wheel fork			
125	3	9598-0002-02	Pin lock			
126	3	1482-0041-00	Cotter bolt			
127	1	9747-0831-02	Lock nut			
128	1	9699-0028-02	Flat washer			
129	1	9997-0855-12	Screw			
130	2	9799-1631-02	Nut			
131	2	9678-0014-02	Lock washer			
132	2	1482-0258-01	Wheel			
133	2	1482-0027-00	Wheel bushing			
134	2	9699-0104-02	Washer			
135	2	9997-1680-12	Screw			
181	1	1482-0092-00	.Pin			
182	1	9598-0002-02	.Pin lock			
183	8	9987-5222-16	.Screw			
184	8	9794-5231-02	.Nut			
185	1	1482-0531-01	Rotor outer assy-R.			

Section: JB 90-JB 921 CHASSIS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1121	1129				
186	8	8	9987-5222-16	.	Screw	
187	8	8	9794-5231-02	.	Nut	
188	4	4	1482-0533-01	.	Rotor blade-R.H.	
190	4	4	1482-0534-01	.	Rotor blade-L.H.	
191	1	1	9598-0002-02	.	Pin lock	
192	1	1	1482-0092-00	.	Pin	
193	1	1	1482-0532-01		Rotor inner assy-R.	
194	1	1	1482-0529-01		Rotor inner assy-L.	
195	1	1	1482-0530-01		Rotor outer assy-L.	
196		1	1482-0543-01		Bumper	
197		2	9799-0831-02		Nut	
198		2	9683-0030-02		Lock washer	
199		2	9997-0855-12		Screw	
200		2	1482-0586-01		Plastic plug	
202	1	1	1482-0583-01		Guard extension-R.H	
203	3	3	9865-0512-16		Screw	
204	3	3	9699-0024-02		Flat washer	
205	3	3	9747-0531-02		Nut	
206	2	2	9997-0616-16		Screw	
207	2	2	9699-0025-02		Washer	
208	2	2	9699-0025-02		Washer	
209	2	2	9683-0025-02		Lock washer	
210	2	2	9799-0631-02		Nut	
211	1	1	1482-0538-01		Mud guard	
212	1	1	1482-0585-01		Fibre stop	
219	1	1	1482-0567-01		Allen wrench	
220	3	3	9865-0512-16		Screw	
221	3	3	9699-0024-02		Flat washer	
222	3	3	9747-0531-02		Nut	
223	1	1	1482-0584-01		Guard extension-L.H	
224	1	1	1482-0581-01		Belt guard	
225	2	2	1482-0580-01		Rubber loop	
226	1	1	1482-0576-01		Wing nut	
228	1	1	1482-0569-01		Dish washer	
229	1	1	9699-0104-02		Washer	