



Section: VILLA ENGINE BRAKE

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
			2858 2859				
			2855 2870 2881				
			2812 2854 2842 2843				
1	4	4	4	4	9739-0831-22	Nut	
2	4	4	4	4	9997-0840-16	Screw	
3			1	1	1134-3582-01	Fuel tank	
4			1	1	1134-2877-02	Fuel tank cap	
5			1	1	1134-3586-01	Strap-short	
6			1	1	1134-3587-01	Strap-long	
7			2	2	9948-0630-16	Screw	
8			2	2	9747-0631-02	Lock nut	
9			1	1	1134-3224-01	Fuel shut-off valve	
10			1	1	1134-3225-01	Grommet	
11	1	1	1	1	1134-1364-02	Spacer ring	
12	1	1	1	1	9600-0250-00	Key	
13			1	1	1134-2350-01	Exhaust pipe	
14			1	1	1134-0433-00	Muffler gasket	
15			1	1	1134-2462-01	Lock	
16			2	2	1134-1565-01	Spacer	
17			2	2	9988-3651-12	Screw	
18			1	1	1134-2394-01	Heat guard	
19			2	2	9739-0831-22	Nut	
20			1	1	1134-3245-02	Muffler	
21			1	1	9578-0011-00	Clamp	
22			1	1	9959-0820-16	Screw	
23			1	1	1134-2354-01	Heat guard	
24			2	2	9997-0612-16	Screw	
30	1	1	1	1	1134-1975-01	Gas control	
31	1	1	1	1	9403-0035-10	Handle	
32	2	2	2	2	9849-8009-16	Screw	
40	1	1	1	1	1134-1979-01	Brake pedal	
41	1	1	1	1	1134-0269-00	Pedal rubber	
42	1	1	1	1	1134-1927-01	Bearing	
43	2	2	2	2	9898-0635-12	Screw	
44	2	2	2	2	9739-0631-22	Nut	
45	1	1	1	1	1134-1980-01	Brake rod	
46	1	1	1	1	1134-1023-00	Spring	
47	1	1	1	1	9595-0160-00	Locating pin	
48	1	1	1	1	9699-0090-02	Flat washer	
49	1	1	1	1	9747-0831-02	Lock nut	
50	1	1	1	1	1134-1889-01	Eyebolt	
51	1	1	1	1	9747-0631-02	Lock nut	
52	1	1	1	1	1134-2138-01	Eye bolt	
53	1	1	1	1	9739-0831-22	Nut	
54	1	1	1	1	4231-0013-00	Spring	
55	1	1	1	1	1134-1937-01	Control lever	
56	1	1	1	1	4231-0013-00	Spring	