



## Section: JB 931 CHAIN CASE

| Pos. | Quantity | Spare part No | Description        | Kit | Notes           | New |
|------|----------|---------------|--------------------|-----|-----------------|-----|
|      | 1230     |               |                    |     |                 |     |
| 600  | 1        | 1482-0248-01  | Plastic plug       |     |                 |     |
| 601  | 1        | 1482-0554-01  | Bushing            |     |                 |     |
| 602  | 1        | 9997-0620-16  | Screw              |     |                 |     |
| 603  | 1        | 9683-0025-02  | Lock washer        |     |                 |     |
| 604  | 1        | 9997-0620-16  | Screw              |     |                 |     |
| 605  | 1        | 9683-0025-02  | Lock washer        |     |                 |     |
| 606  | 1        | 1482-0308-01  | Cover              |     |                 |     |
| 607  | 1        | 1482-0443-01  | Gasket             |     |                 |     |
| 608  | 1        | 1482-0849-01  | Cable holder       |     |                 |     |
| 609  | 1        | 1482-0779-01  | Gear housing assy  |     |                 |     |
| 610  | 1        | 1482-0485-01  | .Needle bearing    |     |                 |     |
| 611  | 1        | 1482-0214-01  | .Oil-seal          |     |                 |     |
| 612  | 1        | 9699-0028-02  | .Flat washer       |     |                 |     |
| 613  | 1        | 1482-0820-01  | .Screw             |     |                 |     |
| 614  | 1        | 9699-0028-02  | .Flat washer       |     |                 |     |
| 615  | 1        | 1482-0820-01  | .Screw             |     |                 |     |
| 616  | 1        | 1482-0458-01  | .Seal              |     |                 |     |
| 617  | 1        | 1482-0459-01  | .Lock ring         |     |                 |     |
| 618  | 1        | 9549-0003-00  | .Ball bearing      |     |                 |     |
| 619  | 1        | 1482-0481-01  | .Spacer            |     |                 |     |
| 620  | 1        | 1489-0412-01  | .Pin               |     |                 |     |
| 621  | 1        | 9595-0500-00  | .Locating pin      |     |                 |     |
| 622  | 1        | 1482-0486-01  | .Shaft w. gear     |     |                 |     |
| 623  | 1        | 1482-0482-01  | .Spacer            |     |                 |     |
| 624  | 1        | 9549-0003-00  | .Ball bearing      |     |                 |     |
| 625  | 1        | 1482-0459-01  | .Lock ring         |     |                 |     |
| 626  | 1        | 1482-0458-01  | .Seal              |     |                 |     |
| 627  | 1        | 1482-0450-01  | .Chain-top         |     |                 |     |
| 628  | 1        | 1482-0473-01  | .Needle bearing    |     |                 |     |
| 629  | 1        | 1482-0452-01  | .Spacer            |     |                 |     |
| 630  | 1        | 1482-0451-01  | .Sprocket          |     |                 |     |
| 631  | 1        | 9660-0200-00  | .Spacer            |     |                 |     |
| 632  | 1        | 1482-0473-01  | .Needle bearing    |     |                 |     |
| 633  | 1        | 9747-0831-02  | .Lock nut          |     |                 |     |
| 634  | 1        | 9699-0028-02  | .Flat washer       |     |                 |     |
| 635  | 1        | 1482-0454-01  | .Chain-middle      |     |                 |     |
| 636  | 1        | 1482-0480-01  | .Oil drain plug    |     |                 |     |
| 637  | 1        | 1482-0479-01  | .Gasket            |     |                 |     |
| 638  | 1        | 1482-0473-01  | .Needle bearing    |     |                 |     |
| 639  | 1        | 1482-0452-01  | .Spacer            |     |                 |     |
| 640  | 1        | 1482-0774-01  | .Chain wheel       |     |                 |     |
| 641  | 1        | 9660-0200-00  | .Spacer            |     |                 |     |
| 642  | 1        | 1482-0473-01  | .Needle bearing    |     |                 |     |
| 643  | 1        | 9699-0025-02  | .Washer            |     |                 |     |
| 644  | 1        | 9747-0831-02  | .Lock nut          |     |                 |     |
| 645  | 1        | 1482-0547-01  | .Chain-lower       |     |                 |     |
| 646  | 1        | 9915-1020-15  | .Screw             |     |                 |     |
| 647  | 1        | 9589-1003-00  | .Sprocket          |     |                 |     |
| 648  | 1        | 1482-0048-01  | .Shaft             |     |                 |     |
| 649  | 1        | 1482-0485-01  | .Needle bearing    |     |                 |     |
| 650  | 1        | 1482-0214-01  | .Oil-seal          |     |                 |     |
| 651  | 1        | 1482-0536-01  | Gear case oil (0.5 |     | Texaco Multifak |     |