



Section: SB 52 BRUSH CUTTER ENGINE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4630					
1	12	1911-3007-01	Screw			
2	1	1911-3160-01	Transm.support case			
3	4	1911-3023-01	Nut			
4	1	1911-3005-01	Screw			
5	1	1911-3016-01	Washer			
6	2	1911-3019-01	Washer			
7	2	1911-3028-01	.Screw			
8	1	1911-3088-01	.Spring			
9	2	1911-3095-01	.Clutch unit			
10A	1	1911-3078-01	.Clutch guide plate			
10B	1	1911-3079-01	.Clutch guide plate			
11	2	1911-3009-01	Screw			
12	2	1911-3017-01	Washer			
13	1	1911-3054-01	Electronic coil			
14	1	1911-3055-01	Spark plug cable			
15	1	1911-3128-01	Wire sheath			
16	1	1911-3092-01	Clamp			
17	1	1911-3060-01	Ground cable			
18	1	1911-3186-01	Flywheel assy		Inkl. pos 7 - 10	
19	2	1911-3020-01	Nut			
20	4	1911-3010-01	Screw			
23	2	1911-3044-01	Seal ring			
24	1	1911-3116-01	Grommet			
25	1	1911-3193-01	Crankcase assy			
26	1	1911-3049-01	Key			
27	1	1911-3041-01	.Needle bearing			
28	1	1911-3185-01	Crankshaft assy		Inkl. pos 27	
29	2	1911-3033-01	Ball bearing			
30	1	1911-3098-01	.Gasket			
31	5	1911-3022-01	Nut			
32	2	1911-3002-01	.Screw			
33	2	1911-3087-01	.Spring			
34	2	1911-3118-01	.Starter hook			
35	1	1911-3194-01	Starter cup assy		Inkl. pos 32 - 34	
37	1	1911-3006-01	Screw			
38	1	1911-3174-01	Cylinder cover			
39	1	1911-3136-01	Muffler			
40	1	1911-3105-01	.Gasket			
41	1	1911-3113-01	Spark plug cover			
42	1	1911-3093-01	Spark plug spring			
43	1	9400-0258-00	Spark plug		Champion CJ7Y	
44	4	1911-3009-01	Screw			
45	1	1911-3099-01	.Cylinder gasket			
46	1	1911-3046-01	..Piston ring			
47	1	1911-3050-01	..Piston pin			
48	2	1911-3068-01	..Lock ring			
49	1	1911-3195-01	.Piston assy		Inkl. pos 46 - 48	
50	1	1911-3196-01	Cylinder assy w.pis		Inkl. pos 49	
51	2	1911-3007-01	Screw			
52	1	1911-3150-01	.Intake filter			
53	1	1911-3209-01	.Grommet assy			
54	1	1911-3207-01	.Fuel cap			
55	1	1911-3147-01	Fuel tank assy		Inkl. pos 52 - 5 4	
56	1	1911-3177-01	Flange			
57	4	1911-3007-01	Screw			
57	4	1911-3006-01	Screw			
58	4	1911-3017-01	Washer			
59	4	1911-3023-01	Nut			
64	1	1911-3206-01	Gasket set		Inkl. pos 30, 40, 4	
67	1	1911-3013-01	Screw			
68	1	1911-3125-01	Spacer			