



## Section: 928-928T-1333 ENGINE

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
	2837	2838	2861				
3	4	4	4	1812-1678-01		Carriage bolt	
5	4	4	4	1812-1681-01		Retainer	
6	4	4	4	9795-3631-02		Nut	
8	1	1	1	1812-1719-01		Engine pulley	
10	1	1	1	1812-1691-01		Washer	
12	1	1	1	9683-0035-02		Lock washer	
14	1	1	1	1133-0762-01		Screw	
16	1	1		1812-9016-01		Drive belt	
16			1	1812-9024-01		V-belt	
18			1	1812-9023-01		V-belt	
18	1	1		1812-9020-01		Drive belt	
20	1	1	1	1812-1742-01		Belt guide	
22	1	1	1	9699-0030-02		Flat washer	
24	1	1	1	9987-5119-16		Screw	
25			1	1812-1740-01		Engine mount plate	
25	1	1		1812-1703-01		Engine mount plate	
26	2	2	2	9988-3516-16		Screw	
27	4	4	4	1812-0385-01		Screw	
28		1		1812-1749-01		Engine box frame	
28			1	1812-1696-01		Engine box frame	
28	1			1812-1695-01		Engine box frame	
30	1	1	1	37102		Starter motor assy	
31	2	2	2	1812-1356-01		Screw	Nedre/lower
31	2	2	2	1812-1616-01		Shoulder screw	Övre/upper
32	2	2	2	1812-1617-01		Screw	
33	1	1	1	1812-1615-01		Extension cord	

test