



## Section: KANZAKI TRANSAXLE K66B

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
K66B						
1	1	1139-1211-01	Transaxle case set			
2	1	1139-1169-01	Upper case assy		Inkl. pos 3-4	
5	1	1139-1212-01	Lower housing			
6	1	1139-1171-01	Oil cap			
7	5	1139-1006-01	Bolt			
8	1	1139-1172-01	Filter			
9	1	1139-1057-01	Magnet assy			
10	1	1139-1179-01	Fitting			
11	2	1139-1277-01	Washer			
12	1	1139-1104-01	Snap ring			
13	2	1139-1116-01	O-ring			
14	1	1139-1119-01	Seal			
15	1	1139-1124-01	Bolt			
16	2	1139-1292-01	Bolt			
17	12	1139-0244-01	Tapping screw			
18	1	1139-1178-01	Center case assy			
18A	2	1139-1231-01	.Knock pin			
18B	1	1139-1176-01	.Valve set			
18C	1	1139-1175-01	.Valve set			
18D	1	1139-1177-01	.Plug			
18E	1	1139-1117-01	.O-ring			
20	2	1139-1117-01	O-ring			
21	1	1139-1158-01	Pin			
23	3	1139-1293-01	Bolt			
24	1	1139-1139-01	Cylinder block assy			
25	1	1139-1214-01	Pump shaft			
26	4	1139-1021-01	Snap ring			
27	1	1139-1110-01	Ball bearing			
28	1	1139-1170-01	Housing			
29	1	1139-1005-01	Thrust bearing			
30	1	1139-1139-01	Cylinder block assy			
31	1	1139-1160-01	Washer			
32	1	1139-1182-01	Motor shaft			
34	1	1139-1183-01	E-ring			
35	1	1139-1215-01	Motor gear			
36	1	1139-1287-01	Ball bearing			
38	2	1139-1022-01	Metal thrust			
39	1	1139-1187-01	Swash plate assy			
40	1	1139-1024-01	Bearing			
41	1	1139-1145-01	Thrust plate			
42	1	1139-1026-01	Thrust plate			
43	1	1139-1028-01	Spring			
44	1	1139-1188-01	Shaft-bypass			
45	1	1139-1189-01	Lever-bypass			
46	1	1139-1161-01	Ring			
47	1	1139-1280-01	Pin			
54	1	1139-1285-01	Pin			
59	1	1139-1165-01	Seal			
60	1	1139-1191-01	Control shaft assy			
61	1	1139-1190-01	Fulcrum			
62	1	1139-1102-01	Washer			
63	2	1139-1115-01	O-ring			
64	1	1139-1127-01	Nut			
66	1	1139-1201-01	Differential gear k			
66A	2	1139-1202-01	Differential gear			
67	2	1139-1203-01	Pin			
68	1	1139-1208-01	Final gear			
69	1	1139-1192-01	Shaft			
70	2	1139-1193-01	Washer			
71	1	1139-1206-01	Reduction gear			
72	1	1139-1209-01	Final pinion			
76	1	1139-1332-01	Axle shaft-left			
77	2	1139-1155-01	Ring			
78	1	1139-1333-01	Axle shaft-right			
79	2	1139-1156-01	Bushing			
80	1	1139-1330-01	Collar			

## Section: KANZAKI TRANSAXLE K66B

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
K66B						
81	2	1139-1044-01	Seal			
82	2	1139-1194-01	Thrust washer			
85	1	1139-1227-01	Brake arm			
86	1	1139-1228-01	Return spring			
87	1	1139-1195-01	Brake disc			
88	1	1139-1196-01	Brake shoe			
89	1	1139-1198-01	Shim set			
90	1	1139-1200-01	Brake actuator			
91	1	1139-1197-01	Brake shaft			
92	1	1139-1199-01	Washer			
93	1	1139-1114-01	O-ring			
100	2	1139-1278-01	Ring			
103	1	1139-1230-01	Cap			
104	1	1139-1290-01	Packing			
105	1	1139-1186-01	Filter			
107	1	1139-1018-01	Spring			
109	1	1139-1184-01	Pump case assy			
109A	1	1139-1153-01	.Valve assy			
109B	1	1139-1154-01	.Valve assy			
109C	1	1139-1234-01	.Check assy			
109D	1	1139-1185-01	.Pump case assy			
109E	1	1139-1167-01	.Plug			
111	2	1139-1235-01	Connector			
112	2	1139-1168-01	Packing			
113	1	1139-1148-01	Pin			
114	2	1139-0239-01	Packing			
115	2	1139-1291-01	Bolt			
117	2	1139-1204-01	Needle bearing			
118	1	1139-1205-01	Collar			
119	1	1139-1146-01	Ring			
120	1	1139-1144-01	Return spring			
121	1	1139-1217-01	Diff. lock fork			
122	1	1139-1218-01	Diff. lock arm			
123	1	1139-1219-01	Diff. lock pivot			
124	1	1139-1220-01	Spring hook			
125	1	1139-1221-01	Arm hold plate			
126	1	1139-1331-01	Diff. lock slider			
127	8	1139-1223-01	Diff. lock pin			
128	1	1139-1224-01	Diff. lock plate			
129	2	1139-1289-01	Packing			
130	1	1139-0244-01	Tapping screw			
131	2	1139-1166-01	Pin			