



M035

Section: KANZAKI TRANSAXLE K46 TRANSAXLE CASE

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
K46F K46S							
3	1	1	1139-1302-01	Upper housing assy		Pos 4 - 5 incl.	
7	1	1	1139-1297-01	Lower housing			
8	1	1	1139-1304-01	Reservoir tank			
9	1	1	1139-1298-01	Tube			
10	2	2	1139-1300-01	Hose clamp			
11	1	1	1139-1100-01	Vent valve assy		Pos 12 - 13 incl.	
14	1	1	1139-1150-01	Magnet			
15	1	1	1139-1240-01	Holder-magnet			
16	1	1	1139-1303-01	Oil seal			
17	1	1	1139-1028-01	Spring			
18	1	1	1139-1324-01	Shaft-bypass			
19	1	1	1139-1189-01	Lever-bypass			
20	1	1	1139-1161-01	Ring			
21	1	1	1139-1275-01	Bore plug			
22	1	1	1139-1104-01	Snap ring			
23	1	1	1139-1279-01	Pin			
24	1	1	1139-1280-01	Pin			
25	2	2	1139-1117-01	O-ring			
26	1	1	1139-1119-01	Seal			
27	14	14	1139-0244-01	Tapping screw			
28	2	2	1139-1295-01	Tapping screw			
29	1	1	1139-1305-01	Tank support			

test