



## Section: VB 38 LAWN COMBER

| Pos. | Quantity | Spare part No | Description       | Kit | Notes | New |
|------|----------|---------------|-------------------|-----|-------|-----|
|      | 2111     |               |                   |     |       |     |
| 1    | 1        | 1621-0075-01  | Delta rotor assy  |     |       |     |
| 2    | 1        | 1621-0032-01  | .Rotor            |     |       |     |
| 3    | 13       | 1621-0044-01  | .Spacer           |     |       |     |
| 4    | 28       | 1621-0068-01  | .Delta blade      |     |       |     |
| 5    | 56       | 9988-3516-16  | .Screw            |     |       |     |
| 6    | 14       | 1621-0043-01  | .Carrier plate    |     |       |     |
| 7    | 56       | 9743-3521-32  | .Nut              |     |       |     |
| 8    | 1        | 1621-0024-01  | .Spacer           |     |       |     |
| 12   | 1        | 1621-0021-01  | .Flat washer      |     |       |     |
| 13   | 1        | 1621-0020-01  | .Lock washer      |     |       |     |
| 14   | 1        | 1621-0010-01  | .Nut              |     |       |     |
| 17   | 5        | 9899-3622-16  | Screw             |     |       |     |
| 18   | 4        | 9677-0009-02  | Lock washer       |     |       |     |
| 19   | 4        | 9795-3631-02  | Nut               |     |       |     |
| 20   | 4        | 1621-0012-01  | Bearing holder    |     |       |     |
| 22   | 2        | 1621-0011-01  | Bearing w. collar |     |       |     |
| 24   | 2        | 1621-0004-01  | .Set screw        |     |       |     |
| 25   | 1        | 1621-0022-01  | Plastic cap       |     |       |     |
| 27   | 2        | 1621-0026-01  | Key               |     |       |     |
| 28   | 1        | 1621-0013-01  | Belt pulley       |     |       |     |
| 29   | 2        | 9913-3609-15  | Screw             |     |       |     |
| 30   | 1        | 1621-0015-01  | V-belt            |     |       |     |
| 32   | 1        | 1621-0014-01  | Engine pulley     |     |       |     |
| 33   | 1        | 1621-0016-01  | Idler pulley      |     |       |     |
| 34   | 1        | 9988-3757-12  | Screw             |     |       |     |
| 35   | 1        | 1621-0039-01  | Idler arm         |     |       |     |
| 36   | 1        | 9785-3731-02  | Nut               |     |       |     |
| 37   | 1        | 1621-0035-01  | Tab               |     |       |     |
| 38   | 10       | 9699-0029-02  | Flat washer       |     |       |     |
| 39   | 5        | 9743-3721-32  | Nut               |     |       |     |
| 42   | 1        | 1621-0041-01  | Cover             |     |       |     |
| 43   | 1        | 9677-0011-02  | Starlock          |     |       |     |
| 44   | 1        | 1621-0007-01  | Cap nut           |     |       |     |
| 45   | 1        | 1621-0030-01  | Belt keeper       |     |       |     |
| 46   | 7        | 9743-3621-32  | Nut               |     |       |     |
| 47   | 1        | 9699-0076-02  | Washer            |     |       |     |
| 48   | 1        | 1621-0017-01  | Clutch spring     |     |       |     |
| 49   | 1        | 1621-0033-01  | Clutch link       |     |       |     |
| 52   | 1        | 9988-3625-16  | Screw             |     |       |     |
| 53   | 17       | 9699-0028-02  | Flat washer       |     |       |     |
| 54   | 1        | 1621-0042-01  | Clutch handle     |     |       |     |
| 55   | 1        | 1621-0023-01  | Handle cap        |     |       |     |
| 56   | 4        | 9599-0070-02  | Split pin         |     |       |     |
| 57   | 4        | 1621-0005-01  | Engine bolt       |     |       |     |
| 58   | 2        | 1621-0046-01  | Reinforcement     |     |       |     |
| 62   | 1        | 1621-0038-01  | Crank             |     |       |     |
| 63   | 10       | 9699-0038-02  | Flat washer       |     |       |     |
| 64   | 1        | 1621-0037-01  | Coupler           |     |       |     |
| 65   | 1        | 1621-0019-01  | Clevis pin        |     |       |     |
| 66   | 1        | 1621-0036-01  | Front wheel axle  |     |       |     |
| 67   | 2        | 9988-3732-12  | Screw             |     |       |     |
| 68   | 4        | 1621-0009-01  | Nut               |     |       |     |
| 69   | 2        | 1621-0052-01  | Front wheel       |     |       |     |
| 70   | 2        | 1621-0053-01  | Rear wheel        |     |       |     |
| 72   | 4        | 1621-0006-01  | Wheel axle bolt   |     |       |     |
| 73   | 4        | 1621-0008-01  | Nut               |     |       |     |
| 74   | 1        | 1621-0031-01  | Deck              |     |       |     |
| 75   | 1        | 1621-0028-01  | Deflector         |     |       |     |
| 76   | 1        | 1621-0034-01  | Deflector strap   |     |       |     |
| 77   | 3        | 9863-3516-16  | Screw             |     |       |     |
| 78   | 3        | 9677-0006-02  | Lock washer       |     |       |     |
| 79   | 3        | 9795-3531-02  | Nut               |     |       |     |
| 82   | 1        | 1621-0018-01  | Roll pin          |     |       |     |
| 83   | 1        | 1621-0027-01  | Locking handle    |     |       |     |
| 84   | 1        | 1621-0029-01  | Pivot pin         |     |       |     |
| 85   | 1        | 1621-0040-01  | Handle upper part |     |       |     |

## Section: VB 38 LAWN COMBER

| Pos. | Quantity | Spare part No | Description      | Kit | Notes               | New |
|------|----------|---------------|------------------|-----|---------------------|-----|
|      | 2111     |               |                  |     |                     |     |
| 86   | 1        | 1621-0001-01  | Foam grip        |     |                     |     |
| 90   | 1        | ..16-2911-11  | Flail rotor assy |     | Tillbehör/Accessory |     |
| 92   | 1        | 1621-0049-01  | .Rotor, flail    |     |                     |     |
| 93   | 4        | 1621-0070-01  | .Blade shaft     |     |                     |     |
| 94   | 1        | 1621-0050-01  | .Blade set       |     | 24 st               |     |
| 95   | 20       | 1621-0071-01  | .Rubber spacer   |     |                     |     |
| 95   | 4        | 1621-0072-01  | .Rubber spacer   |     |                     |     |

test