



Section: PARK 12HST-16HST DRIVE PEDAL CRUISE CONTROL

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1318	1418				
	1358	1458				
2	1	1	1134-2739-01		Pedal	
4	2	2	1134-2780-01		Bearing	
5	2	2	1134-2700-01		Bracket	
6	4	4	9959-0820-16		Screw	
7	9	9	9739-0831-22		Nut	
8	1	1	1134-2703-01		Lever	
12	1	1	1134-2766-01		Speed control wire	
14	2	2	9595-0235-00		Locating pin	
17	1	1	1134-2030-04		Clutch cable	
18	1	1	1134-2991-01		Eye bolt	
20	1	1	9747-0531-02		Nut	
23	1	1	1134-3450-01		Brake pedal (L. H.)	
24	1	1	1134-0269-00		Pedal rubber	
35	1	1	1134-0266-00		Attaching clamp	
37	3	3	9997-0520-16		Screw	
45	1	1	1134-2721-01		Control rod	
46	1	1	1134-2786-01		Plastic knob	
47	1	1	1134-2789-01		Bracket	
48	1	1	1134-2790-01		Rubber grommet	
50	3	3	9959-0816-16		Screw	
51	1	1	9675-0012-02		Locking washer	
52	1	1	9570-0001-00		Elbow link	
56	1	1	1134-2758-01		Spacer	
74	1	1	1134-2707-01		Arm	
79	1	1	9699-0090-02		Flat washer	
80	1	1	9959-0830-16		Screw	
81	1	1	9997-0870-16		Screw	
103	1	1	9997-0835-12		Screw	
108	6	6	9739-0531-22		Nut	
113	1	1	1134-0267-00		Clamp plate	
117	1	1	1134-2859-01		Magneto assy	
118	1	1	1134-2858-01		Spring	
119	1	1	1134-2862-01		Lever	
121	1	1	1134-2866-01		Plate	
122	1	1	1134-2857-01		Switch	
123	1	1	1134-2867-01		Cable harness	
124	1	1	1134-2871-01		Relay	
125	1	1	1134-2902-01		Symbol plate-green	
126	1	1	1134-2933-01		Switch console	
127	1	1	1134-2932-01		Switch	
128	2	2	9849-7819-16		Screw	