



## Section: PARK 16HST ENGINE BRAKE SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1418					
	1458					
1	1	1134-2878-01	Fan cover			
2	4	9997-0512-16	Screw			
5	4	9699-0099-02	Washer			
6	7	9739-0831-22	Nut			
7	4	9997-0835-12	Screw			
8	1	1134-2879-01	Exhaust pipe			
13	1	1134-3244-01	Silencer			
14	1	9959-0816-16	Screw			
15	1	9578-0011-00	Clamp			
16	2	9799-0831-02	.Nut			
22	2	1134-2941-01	Protection strip			
23	1	1134-2886-01	Fuel tank			
24	1	1134-2877-02	.Fuel tank cap			
25	1	9997-0812-02	Screw			
26	1	9747-0831-02	Lock nut			
27	1	1134-1975-10	Gas control			
30	1	1134-2872-01	Choke control			
31	1	9699-0028-02	Flat washer			
32	1	9403-0035-10	Handle			
33	2	9849-8013-16	Screw			
34	1	9579-0008-00	Cable holder			
35	1	9699-0062-02	Flat washer			
37	1	1134-3450-01	Brake pedal (L. H.)			
38	1	1134-9024-01	.Bearing			
39	1	1134-0269-00	Pedal rubber			
40	1	1134-2030-10	Brake cable			
41	1	1131-1506-00	Spring			
42	1	1134-1242-02	Spring			
43	1	9646-0036-22	Rivet			
44	1	9675-0008-02	Locking washer			
45	1	1134-1184-02	Bracket			
46	1	1134-2151-02	Stop			
47	1	1131-1497-01	Spring			
48	1	1134-0245-00	Shoulder screw			
49	1	9959-0820-16	Screw			
50	2	1134-2988-01	Gasket-exhaust			
51	1	9997-0520-16	Screw			
52	1	1134-2998-01	Hose clamp			
53	1	9578-0016-00	Clamp			
54	1	1134-2975-01	Fuel hose			