



Section: VILLA CHASSIS ELECTRICAL SYSTEM

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2816	2828				
	2856	2812	2858			
1		1	1134-1963-07	Engine casing assy		
1	1	1	1134-1963-05	Engine casing assy		
4	1	1	9699-0054-02	.Flat washer		
5	2	2	9405-0029-00	.Knob		
6	3	3	9632-0516-00	.Pop rivet		
7	1		1134-2358-01	Engine cover	Inkl.pos. 25	
7		1	1134-2855-02	Engine cover-black		
7		1	1134-3591-01	Engine cover		
12	2	2	9403-0015-70	Plug		
13	2	2	1134-1643-01	Rubber hose		
14	1	1	1134-1595-02	Tube		
15	1	1	9501-0500-00	Grease joint		
16	2	2	9739-0831-22	Nut		
17	2	2	9959-0816-16	Screw		
20	1	1	1134-3536-01	Floor mat		
21	1	1	1134-9028-01	Rubber strap kit	Inkl.pos. 2	
22	2	2	9849-8013-16	Screw		
23	2	2	9699-0087-02	Flat washer		
25	1	1	1134-2267-01	.Guarding net		
30	1	1	9400-0086-00	Battery-w/o acid		
31	1	1	1134-2333-01	Battery pad		
32	1	1	1134-1922-01	Battery plate		
33	1	1	9400-0064-02	Battery holder		
34	1	1	9942-0612-16	Screw		
35	1	1	1131-1455-00	Battery cable (-)		
37	1	1	1134-0234-01	Battery cable (+)		
39		1	1134-3250-01	Harness		
39	1	1	1134-3270-01	Harness		
41	1	1	1134-1814-01	Starter switch assy		
41A	1	1	1134-2853-01	.Washer		
41B	1	1	1134-2852-01	.Nut		
42	1	1	1134-2848-01	.Ignition key		
43	1	1	9400-0105-01	Switch		
43		1	9400-0105-02	Transmission switch		
44	4	2	9849-8009-16	Screw		
45	1	1	1134-2962-01	Solenoid assy		
46	2	2	9794-5131-02	.Nut		
52	1	1	1134-2310-01	Guard cap		
56	1	1	1134-3300-01	Battery acid	2 x 0.85 liter	
57		1	1134-2352-02	Tow bar		
58		1	9959-0820-16	Screw		
59		1	1134-3251-01	Bracket		
60		2	9959-0612-16	Screw		
61		2	9739-0631-22	Nut		
62		1	1134-3156-01	Switch (black)		
63		1	1134-3204-01	Cable holder		
99	1	1	1134-3557-01	Decal kit		