



STIGA
182A
SPARE PARTS

Section: TRANSMISSION ASSY TURBO 460-510 MULTICLIP S TORNADO 90-900

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

2820	2820	2820	2820			
-12	-24	-33	-34			

0	1			1111-2255-01	Transmission assy	Turbo 510 (alum)
0		1		1111-2564-01	Transmission assy	Tornado 90-900
0			1	1111-2641-01	Transmission assy	Multiclip S
0	1			1111-1186-01	Transmission assy.	Turbo 460-510 (plas
1	2	2	2	9659-0050-04	.Lock ring	
2	1	1	1	F000-4020-00	.Housing, upper, fi	
3	4	4	4	F000-3035-00	.Screw	
4	1	1	1	F000-3346-00	.Screw	
5	1	1	1	F000-3574-00	.Washer, flanged	
6			1	F000-5297-00	.Clutch lever	
6	1	1		F000-3090-00	.Lever, clutch	
7	ERF	ERF	ERF	F000-1544-00	.Washer, plain	19 x 13 x 0.38 mm
7	ERF	ERF	ERF	F000-3121-00	.Washer, plain	24 x 13 x 0.76 mm
7	ERF	ERF	ERF	F000-3194-00	.Washer, plain	25 x 13 x 0.51 mm
7	ERF	ERF	ERF	F000-3889-00	.Washer	24 x 13 x 0.66 mm
8			1	F000-5294-00	.Input shaft	
8	1	1		F000-3584-00	.Shaft, worm input	
9	1	1	1	F000-3475-00	.Key	
10	1	1	1	F000-3095-00	.Gasket	
11	1	1	1	F000-2720-00	.Housing, lower	
14	2	2	2	F000-3278-00	.Pin, spring	
15	1	1	1	F000-3082-00	.Key	
16		1		F000-3985-00	.Shaft, output	
16			1	F000-5295-00	.Output shaft	
16	1			F000-3480-00	.Shaft, output	
16			1	F000-5296-00	.Output shaft	
17	1	1	1	F000-1599-00	.Washer, plain	
20	2	2	2	F000-2711-00	.Bearing & seal	
21	1	1	1	F000-3121-00	.Washer, plain	
22	1	1	1	F000-4013-00	.Kit, gear & clutch	
23	1	1	1	F000-3194-00	.Washer, plain	
35	1	1	1	1111-1843-01	Special grease	