



Section: 1400 ELECTRIC CHAIN SAW

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	3211					
1	1	M40800-00	Sprocket cover			
2	2	M22279-00	Nut			
3	1	M40817-96	Plate-bar tension			
4	1	M40925-63	.Adjusting screw			
5	1	M110807	.Screw			
6	1	M40900-99	.Nut-bar adjusting			
7	1	M15140-99	Screw			
8	1	M40925-70	Housing assy (rh+lh)			
9	8	M15031-99	Screw			
10	1	M40925-70	Housing assy (rh+lh)			
11	1	M40808-00	.End cover			
12	1	M40929-50	Motor & chassis ass			
13	1	M22209-01	Cooling fan			
14	1	M12775-00	Washer			
15	1	M36017-99	Retaining ring			
16	1	M40807-96	Brake lever			
17	1	M40835-00	Axle-brake lever			
18	2	M40815-00	Bar bolt			
19	1	M40933-00	Micro switch			
20	1	M40925-11	Lever-micro switch			
21	1	M12354-96	Connection cable as			
22	1	M12354-00	.Cord			
23	1	M40931-00	.Switch			
24	1	M12228-01	.Cord protector			
25	1	M00498-00	Clamp-cord			
26	2	M15145-99	Screw			
27	1	M40819-96	Oil tank-tubing-fil			
28	1	M40820-02	Cap-oil tank			
29	1	M40925-19	Oil pump-tubing			
30	1	M15117-99	Screw			
31	1	M40925-42	Brake drum and spro			
32	1	M22257-00	Flat washer			
33	1	M40814-00	Washer-sprocket			
34	1	M22237-00	Retaining ring-spro			
38	1	M247098B	Bar		12"	
38A	1	M240451	Plastic guard 12"		Ej ill/not ill.	
39	1	M852312BS	Chain		3/8" (MP 370 GL)	
99	1	M85687	Wrench 11 mm		11 mm	