



STIGA
303C
SPARE PARTS

Section: SWEEPER ART.NO 13-1933-11 ART.NO 13-1934-12 CHASSIS

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------|---------------------|-------|-----|
| | 1933 | 1934 | | | | |
| 0 | | 1 | ..13-1934-12 | Sweeper assy | Villa | |
| 0 | 1 | | ..13-1933-11 | Sweeper assy | Park | |
| 5 | 1 | 1 | 1134-2552-01 | Mounting frame | | |
| 6 | 4 | 4 | 9959-0816-16 | Screw | | |
| 7 | 2 | 2 | 9997-0814-02 | Screw | | |
| 9 | 10 | 10 | 9739-0831-22 | Nut | | |
| 10 | 2 | 2 | 1134-2694-01 | Pivot wheel-rear | | |
| 18 | 2 | 2 | 9997-1030-16 | Screw | | |
| 19 | 2 | 2 | 9739-1031-22 | Nut | | |
| 21 | 2 | 2 | 1134-2684-01 | Bearing | | |
| 23 | 1 | 1 | 1134-2564-01 | Shaft | | |
| 25 | 3 | 3 | 9595-0209-00 | Locating pin | | |
| 27 | | 1 | 1134-2695-01 | Mounting | | |
| 27 | 1 | | 1134-2760-01 | Mounting | | |
| 32 | 1 | 1 | 1134-2756-01 | Wheel support front | | |
| 33 | 2 | 2 | 9997-0840-16 | Screw | | |
| 35 | 2 | 3 | 9739-0631-22 | Nut | | |
| 36 | 1 | 1 | 1134-2607-01 | Tube | | |
| 37 | 2 | 2 | 1134-2608-02 | Spacer | | |
| 38 | 1 | 1 | 9699-0042-02 | Flat washer | | |
| 39 | 1 | 1 | 1134-2604-01 | Pivot wheel bracket | | |
| 40 | 1 | 1 | 9997-1212-02 | Screw | | |
| 42 | 1 | 1 | 9747-1231-02 | Lock nut | | |
| 43 | 1 | 1 | 1134-3569-01 | Lifting rod | | |
| 44 | 1 | 1 | 9403-0100-70 | Handle grip | | |
| 45 | 1 | 1 | 9997-0640-12 | Screw | | |
| 46 | 1 | 1 | 1134-2768-01 | Shaft | | |
| 48 | 1 | 1 | 9997-0845-12 | Screw | | |
| 49 | 1 | 1 | 9747-0831-02 | Lock nut | | |
| 52 | 1 | 1 | 9699-0069-02 | Flat washer | | |
| 55 | 1 | 1 | 1134-2578-01 | Compression spring | | |
| 56 | 2 | 2 | 9548-0015-00 | Bronze bearing | | |
| 57 | 2 | 2 | 1134-2629-01 | Lift link | | |
| 58 | | 1 | 1134-0857-00 | Trippet | | |
| 61 | 1 | 1 | 1134-2630-01 | Link | | |
| 62 | 1 | 1 | 9405-0031-00 | Eye-bolt | | |
| 63 | 1 | 1 | 1134-0576-00 | Link key | | |
| 64 | 1 | 1 | 9747-0831-02 | Lock nut | | |
| 65 | 1 | 1 | 9699-0035-02 | Flat washer | | |
| 68 | 1 | 1 | 9598-0003-02 | Spring pin | | |
| 72 | | 1 | 1134-2617-01 | Protection shield | | |
| 72 | 1 | | 1134-2617-02 | Protection shield | | |
| 75 | 1 | 1 | 1134-2614-01 | Shield bracket | | |
| 76 | 1 | 1 | 1134-2618-01 | Bar | | |
| 77 | 2 | 2 | 9959-0825-16 | Screw | | |
| 80 | 2 | 2 | 1134-2628-01 | Protection shield-L | | |
| 81 | 2 | 2 | 9959-0612-16 | Screw | | |
| 86 | 1 | 1 | 1134-2608-01 | Spacer | | |
| 87 | 2 | 2 | 1611-0027-01 | Rim | | |
| 88 | 1 | 1 | 9545-0108-00 | Tyre | | |
| 89 | 1 | 1 | 9545-0209-00 | Inner tube | | |
| 90 | 2 | 2 | 9549-0043-00 | Ball bearing | | |
| 93 | 6 | 6 | 9947-0616-16 | Screw | | |
| 95 | 3 | 3 | 9403-0044-70 | Plug | | |
| 96 | 3 | 3 | 1134-2609-01 | Knob | | |
| 97 | 1 | 1 | 1134-2559-01 | Mounting bracket | | |
| 100 | 2 | | 9997-1035-16 | Screw | | |
| 101 | 3 | 1 | 9739-1031-22 | Nut | | |
| 102 | | 2 | 1134-1726-01 | Sleeve | | |
| 106 | 4 | 4 | 9959-0820-16 | Screw | | |
| 107 | | 1 | 9997-0640-12 | Screw | | |
| 108 | 1 | 1 | 9997-1040-12 | Screw | | |