



Section: PARK HST DRIVPEDAL FARTHÅLLARE

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|---------------------|---------------|-------------|-----|----------------------------------|---------|
| | 1358 1458 | | | | | |
| | 1443 1446 1818 1448 | | | | | |
| 1 | 1 | 1 | 1 | 1 | 1134-2754-01 Slip protection | -960415 |
| 2 | 1 | 1 | 1 | 1 | 1134-2739-01 Pedal | -960415 |
| 2 | 1 | 1 | 1 | 1 | 1134-3706-01 Pedal | 960416- |
| 3 | 1 | | | | 1134-1643-01 Rubber hose | -960415 |
| 3 | | 1 | 1 | 1 | 1134-2849-01 Rubber hose | 960416- |
| 3 | | 1 | 1 | 1 | 1134-2849-02 Rubber hose | -960415 |
| 3 | 1 | | | | 1134-2849-03 Rubber hose | 960416- |
| 4 | 2 | 2 | 2 | 2 | 1134-2780-01 Bearing | |
| 5 | 2 | 2 | 2 | 2 | 1134-2700-01 Bracket | |
| 6 | 2 | 2 | 2 | 2 | 9959-0820-16 Screw | |
| 7 | 5 | 7 | 7 | 7 | 9739-0831-22 Nut | |
| 8 | 1 | 1 | 1 | 1 | 1134-3704-01 Lever | 960416- |
| 8 | 1 | 1 | 1 | 1 | 1134-2703-01 Lever | -960415 |
| 9 | 2 | 2 | 2 | 2 | 9997-0520-16 Screw | 960416- |
| 10 | 2 | 2 | 2 | 2 | 9739-0531-22 Nut | 960416- |
| 12 | | 1 | 1 | 1 | 1134-2766-02 Speed control wire | |
| 12 | 1 | | | | 1134-2766-03 Speed control wire | |
| 14 | 1 | 2 | 2 | 2 | 9595-0235-00 Locating pin | -960415 |
| 17 | 1 | | | | 1134-2030-11 Clutch cable | |
| 17 | | 1 | 1 | 1 | 1134-3584-01 Brake/clutch wire | |
| 18 | 1 | | | | 1134-2991-01 Eye bolt | |
| 19 | 1 | 1 | 1 | 1 | 1131-1506-00 Spring | |
| 20 | 1 | | | | 9747-0531-02 Nut | |
| 23 | 1 | 1 | 1 | 1 | 1134-3450-01 Brake pedal (L. H.) | |
| 24 | 1 | 1 | 1 | 1 | 1134-9024-01 .Bearing | |
| 25 | 1 | 1 | 1 | 1 | 1134-0269-00 Pedal rubber | |
| 35 | 1 | 1 | 1 | 1 | 1134-0266-00 Attaching clamp | |
| 37 | 2 | 3 | 3 | 3 | 9997-0520-16 Screw | |
| 50 | | 2 | 2 | 2 | 9959-0816-16 Screw | |
| 52 | 1 | 1 | 1 | 1 | 9570-0001-00 Elbow link | |
| 81 | 1 | 1 | 1 | 1 | 9997-0870-16 Screw | |
| 103 | 1 | 1 | 1 | 1 | 9959-0816-16 Screw | |
| 108 | 5 | 5 | 5 | 5 | 9739-0531-22 Nut | |
| 113 | 1 | 1 | 1 | 1 | 1134-0267-00 Clamp plate | |
| 117 | | 1 | 1 | 1 | 1134-2859-01 Magneto assy | |
| 118 | | 1 | 1 | 1 | 1134-2858-01 Spring | |
| 119 | | 1 | 1 | 1 | 1134-2862-01 Lever | |
| 121 | | 1 | 1 | 1 | 1134-2866-02 Plate | |
| 122 | | 1 | | 1 | 1134-2857-01 Switch | |
| 123 | | 1 | | 1 | 1134-3640-01 Harness | |
| 124 | | 1 | 1 | 1 | 1134-2871-01 Relay | |
| 125 | | 1 | | 1 | 1134-2902-01 Symbol plate-green | |