



## Section: MULTICLIP 46S-46SE TRANSMISSION

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
	3615	3619	3637				
1	1	1	1	1111-2900-01	Wheel mounting-R.H.		
2	1	1	1	1111-2901-01	Wheel mounting-L.H.		
3	2	2	2	9548-0014-00	.Bronze bearing		
4	1	1	1	1111-2549-01	.Plastic knob		
5	2	2	2	1111-3065-01	Spacer		
6	2	2	2	1111-2561-01	Cover plate		
7	2	2	2	1111-2382-01	Pin		
8	2	2	2	1111-2635-02	Gear wheel		
9	2	2	2	9699-0100-02	Washer		
10	2	2	2	9943-0612-16	Screw		
16	2	2	2	9699-0037-02	Washer		
17	2	2	2	1111-1138-01	Spring		
18	2	2	2	1111-2665-01	Wheel assy		
19	1	1	1	1111-9047-01	.Ball bearing kit		
20	2	2	2	1111-1184-01	..Bearing cone		
21	2	2	2	9699-0100-02	Washer		
22	2	2	2	9943-0612-16	Screw		
23	2	2	2	1111-2664-01	Hub cap		
24	2	2	2	1111-2676-01	Wheel cup		
30	1	1	1	1111-2633-01	Front cover-yellow		
31	1	1	1	9943-0530-16	Screw	L = 30 mm	
32	2	2	2	9943-0540-16	Screw	L = 40 mm	
33	2	2	2	9739-0531-22	Nut		
40	1	1	1	1111-9051-01	Drive belt		
41	1	1	1	1111-2915-01	Engine belt pulley		
42	1	1	1	9910-0612-16	Set screw		
45	1	1	1	1111-3055-01	Transmission assy		
49	1	1	1	1111-3060-01	Spring		
55		2		9836-9520-12	Screw		
56		1		9400-0186-00	Starting switch ass		
57		1		1134-2848-01	.Ignition key		
58		1		1111-2707-01	Housing		
59		1		1111-2705-01	Cover		
60		1		1111-2562-02	Harness		
65	1	1	1	1111-2965-03	Clutch control		
66	2	2	2	9747-0631-02	Lock nut		
67	2	2	2	9948-0655-16	Screw		
68	1	1	1	9836-9512-12	Screw		
69		2		9865-0580-16	Screw		
70		2		9693-0004-02	Washer		
71		1		1111-2733-01	Cover		
72		1		9400-0218-00	Battery		
73		1		9400-0219-00	Charger		
74		2		9739-0531-22	Nut		
75	1	1	1	1111-2018-01	Cable holder		
76	1	1	1	9836-9216-12	Screw		
77	1	1	1	9579-0008-00	Cable holder		
78	1	1	1	1111-1987-02	Control knob-black		