



Section: VILLA STEERING

Pos.	Quantity		Spare part No	Description	Kit	Notes	New
		2858	2881				
		2855	2842	2843			
1	4	4	4	1134-0041-01	Bushing		
2	1	1	1	1134-3022-01	Cable holder		
3	3	3	3	1134-3022-01	Cable holder		
4	2	2	2	1134-9025-01	Steering pulley-kit	Sats 2 st/kit of 2	
5	4	4	4	9942-1030-16	Screw		
6	1	1	1	1134-9023-01	Steering wire		
7	1	1	1	1134-1310-01	Compression spring		
8	1	1	1	9699-0090-02	Flat washer		
9	1	1	1	9747-0831-02	Lock nut		
10	1	1	1	9959-0816-16	Screw		
11	1			1134-2390-01	Steering wheel		
11		1	1	1134-3754-01	Steering wheel w.kn		
12		1	1	1134-3769-01	.Steering wheel but		
13		1	1	1134-3752-01	..Knob holder		
14		1	1	9997-0865-12	..Screw		
15		1	1	1134-1565-06	..Spacer		
16		2	2	9699-0090-02	..Flat washer		
17		1	1	9747-0831-02	..Lock nut		
18		1	1	9403-0043-70	..Plug		
19		1	1	9403-0113-00	..Nut cap		
20	1	1	1	1134-1424-01	Steering column		
21	1	1	1	1134-1933-01	Steering pulley		
22	1	1	1	9595-0262-00	Locating pin		
23	2	2	2	1134-1901-01	Bearing		
30		1	1	1134-3538-01	Rear weight (no spa	2842, 2843 (US, CA)	
31		2	2	9997-1080-12	Screw		
32		2	2	9699-0035-02	Flat washer		
40	1	1	1	1134-0341-01	Washer		
41	2	2	2	1134-3247-02	Tie rod		
42	1	1	1	1134-1428-01	Spindle-L.H.		
43	1	1	1	1134-1428-02	Spindle-R.H.		
44	1	1	1	1134-1500-02	Steering pulley		
45	1	1	1	1134-9024-01	Bearing	Sats 4 st/kit of 4	
46	1	1	1	1134-1583-01	Shaft-steering pull		
47	1	1	1	1134-1634-01	Rear axle		
47	1	1	1	1134-1634-02	Rear axle (no spare	2842, 2843 (US, CA)	
48	2	2	2	9501-0500-00	Grease joint		
49	3	3	3	9650-0020-04	Circlip		
50	2	2	2	9699-0088-02	Flat washer		
51	4	4	4	9747-0831-02	Lock nut		
52	2	2	2	9699-0028-02	Flat washer		
53	4	4	4	9997-0825-16	Screw		
54	1	1	1	9501-0500-00	Grease joint		
55	1	1	1	9650-0020-04	Circlip		
56	1	1	1	9699-0088-02	Flat washer		
57	2	2	2	1134-2669-02	Rim assy		
58	1	1	1	1134-9026-01	.Bearing bush kit	Sats 4 st/kit of 4	
59	2	2	2	9545-0117-00	Tyre	13 x 5.00-6	
59A				9545-0204-00	Inner tube	Reservdel/spare par	
60	2	2	2	9545-0500-00	Valve		
61	2	2	2	1134-0341-01	Washer		
62	2	2	2	9650-0020-04	Circlip		
70	1	1	1	9595-0262-00	Locating pin		
71	1	1	1	9699-0114-02	Flat washer	1.0 mm	
71	1	1	1	9699-0103-02	Flat washer	0.5 mm	