


4 - SPEED



Section: TURBO 43-43S-43SE TRANSMISSION

Pos.	Quantity					Spare part No	Description	Kit	Notes	New
		1601								
		1690								
	1390	1699	1490	1499						
1	1	1	1	1	1111-3114-01	Rear axle				
2	2	2	2	2	1111-2814-01	Bushing				
3	4	4	6	6	9947-0616-16	Screw				
4	5	5	7	7	9838-9522-12	Screw				
5	1	1	1	1	1111-2798-01	Height adj.quadrant				
6	1	1	1	1	1111-2816-01	Height adj.lever				
7	1	1	1	1	1111-2817-01	Lever knob				
8	2	2	2	2	9943-0612-16	Screw				
10	2	2	2	2	1111-2665-01	Wheel assy				
11	2	2	2	2	1111-9047-01	.Ball bearing kit				
12	2	2	2	2	1111-1184-01	.Bearing cone				
15	2	2	2	2	9699-0100-02	Washer				
16	2	2	2	2	9943-0612-16	Screw				
17	2	2			1111-3085-05	Hub cap-blue				
17	2	2	2	2	1111-3085-01	Hub cap-yellow				
20	2	2	2	2	1111-3060-01	Spring				
21	2				1111-2782-01	Wheel cover				
22		2	2	2	1111-2561-01	Cover plate				
23		1			1111-2915-01	Engine belt pulley				
24		1	1	1	9910-0612-16	Set screw				
25		1			1111-9053-01	Drive belt				
26		1	1	1	1111-3111-01	Transmission assy				
27		1			1111-3047-01	Belt pulley				
28		1			9594-0235-00	Pin				
30		1			1111-2822-01	Tension spring				
31		2	2	2	1111-2382-01	Pin				
32		2	2	2	1111-2827-01	Drive key				
33		2	2	2	9404-0083-00	Seal ring				
36		4	4	4	9695-0013-00	Washer				
37		2	2	2	1111-2829-01	Lock washer				
38		2	2	2	1111-3075-01	Pinion-plastic whee				
39		2	2	2	1111-2830-01	Support washer				
41		2	2	2	9652-0010-04	Snap ring				
45		1			1111-2967-01	Clutch cable		Honda		
45		1	1	1	1111-2967-02	Clutch cable		Briggs & Stratton		
47		1	1	1	1111-2954-01	Control handle				
48	1	1	1	1	1111-2969-01	Cable attachment				
49	1	1	1	1	9948-0640-16	Screw		L = 40 mm		
49		1			9948-0660-16	Screw		L = 60 mm		
50	1	1	2	2	9747-0631-02	Lock nut				
51	1				1111-2924-02	Axle				
52	2				9675-0017-02	Lock washer				
53	1	1	1	1	1111-3102-01	Cover-yellow				
53	1	1			1111-3102-12	Cover-grey				
54			2	2	9838-9540-12	Screw				
55		1	1	1	1111-2971-06	Variator control				
57		1	1	1	1111-2941-01	.Knob				
58		1	1	1	1111-3050-01	Bracket				
61		1	1	1	9594-0026-00	Locating pin				
62		1	1	1	1111-2469-01	Attachment				
63		1	1	1	9943-0650-16	Screw				
64		1	1	1	1111-2423-01	Spacer				
65		1	1	1	1111-2433-01	Engine belt pulley				
66		1	1	1	9585-0090-00	Drive belt				
67		1	1	1	1111-2942-01	Tension arm				
68		1	1	1	9997-0630-12	Screw				
69		1	1	1	1111-2747-01	Tension roller				
70		1	1	1	1111-2746-01	Belt pulley				
71			1	1	1111-3001-01	Variator assy				