



Section: SWEEPER ART.NO 13-1933-11 ART.NO 13-1934-12 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1933	1934				
0		1	..13-1934-12	Sweeper assy	Villa	
0	1		..13-1933-11	Sweeper assy	Park	
2	1	1	1134-2762-01	Case		
4	1	1	1134-2763-01	Transmission cover		
6	1	1	9500-9982-00	Oil plug		
7	2	2	9591-0020-00	Pin		
8	9	9	9997-0635-12	Screw		
10	14	14	9739-0631-22	Nut		
11	5	5	9997-0670-12	Screw		
12	1	1	1134-2584-01	Sprocket		
13	1	1	9907-1020-19	Set screw		
14	1	1	9695-0006-00	Washer		
16	2	2	9549-0045-00	Ball bearing		
17	2	2	9404-0074-00	Seal ring		
18	1	1	1134-2585-01	Output shaft		
21	1	1	1134-2674-01	Sprocket assy	Pos. 22-30,39-40	
22	1	1	1134-2587-01	.Sprocket		
23	1	1	1134-2588-01	.Shaft		
25	1	1	9600-0148-00	.Flat key		
26	1	1	9650-0017-04	.Retaining ring		
27	2	2	9695-0005-00	.Washer		
30	2	2	9549-0017-00	.Ball bearing		
31	1	1	9589-0013-00	Chain		
32	1	1	1134-2589-01	Chain tensioner		
33	1	1	1134-2590-01	Compression spring		
34	1	1	1111-1706-01	Clamp		
35	1	1	9943-0510-16	Screw		
39	2	2	9549-0019-00	.Ball bearing		
40	3	3	9695-0005-00	.Washer		
42	1	1	9651-0040-04	Retaining ring		
43	1	1	1134-2757-01	Drive sheave		
44	1	1	9600-0145-00	Flat key		
45	1	1	9699-0056-02	Flat washer		
47	1	1	9958-0820-16	Screw		
65	1		1134-9041-01	V-belt	=9585-0067-00	
65		1	1134-9042-01	V-belt	=9585-0068-00	
68		2	1134-2796-01	Screw		
68	2		1134-2796-02	Screw		
72	2	2	9591-0031-00	Pin		
75	22	18	1134-2794-01	Brush		
76	2	2	1134-2794-02	Brush		
77	20	16	1134-2795-01	Spacer ring		
78		2	1134-2798-01	Carrier		
78	2		1134-2798-02	Carrier		
79	2	2	1134-2619-01	Washer		
82	2	2	1134-2620-01	Washer		
83	8	8	9942-0825-16	Screw		
84	8	8	9632-0509-00	Pop rivet		
85	1	1	9404-0073-00	Seal ring		
92		1	1134-1446-01	Spring		
93		1	1134-9027-01	Tension roller		
94		1	9699-0035-02	.Flat washer		
95		1	9997-1035-16	Screw		
96		2	9699-0035-02	Flat washer		