



## Section: PARK PRESIDENT-ROYAL HAND CONTROLS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	6113	6114				
1	1	1	1134-4156-01		Panel bracket-inner	
2	2	2	9897-0820-16		Screw	
3	2	2	9739-0831-22		Nut	
5	1	1	1134-4065-01		Control shaft	
6	1	1	1134-4079-01		Spring	
7	1	1	1134-4080-03		Control sleeve	
8	2	2	9959-0820-16		Screw	
9	1	1	1134-4077-01		Throttle control	
10	1	1	1134-4078-01		Knob	
11	1	1	1134-0240-00		Shoulder screw	
12	2	2	1134-4242-01		Spacer washer	
13	1	1	9694-0001-00		Washer	
14	1	1	9739-0831-22		Nut	
15	1		1134-4197-01		Throttle cable	
15		1	1134-4195-02		Throttle cable	
16	1	1	1134-3240-01		Wire clamp	
17	1	1	9943-0516-16		Screw	
18	1	1	1134-4072-01		Control lever	
19	1	1	1134-2551-01		Knob	
20	1	1	1134-3573-03		PTO cable	
21	1	1	1134-4217-01		Switch bracket	
22	2	2	9893-0616-16		Screw	
23	1	1	9400-0285-01		Switch	
24	2	2	9840-7716-16		Screw	
25	1	1	1134-4066-01		Panel bracket-front	
26	2	2	9893-0616-16		Screw	
27	1	1	1134-3986-01		Front plate	
28	4	4	9893-0616-16		Screw	
29		2	1134-2871-03		Relay	
30		3	9997-0520-16		Screw	
31		3	9739-0531-22		Nut	
32	1		1134-3981-05		Dashboard	
32		1	1134-3981-02		Dashboard	
33	4	4	9946-0525-16		Screw	
34	1	1	1134-4154-01		Cover	
35	6	5	1134-4129-01		Cover	
36	1	1	1134-4093-01		Ignition switch	
37	1	1	1134-4097-01		Cap	
38	2	2	1134-4096-01		Ignition key	
39	1	1	1134-4095-01		Nut	
40		1	1134-2872-03		Choke control	
40A		1	1134-4338-01		.Control knob	
41		2	9699-0028-02		Flat washer	
42		1	9400-0282-01		Switch w.diode	
43		1	9400-0280-02		Cover-cruise contro	
44	1	1	1134-4179-01		Hour meter	
45	1		1134-4100-01		Plug	
46		1	1134-0994-01		Tube clamp	
51		1	1134-2871-01		Relay	
99		1	9400-0290-01		Tool for cover	Tillbehör/Accessory