



Section: SH 40 HEDGE CUTTER

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
5211						
1	1	1911-1024-01	Housing-R.H.			
2	1	1911-1025-01	Housing-L.H.			
3	1	1911-1111-01	Handle-lower part			
4	1	1911-1112-01	Handle-upper part			
5	1	1911-1113-01	Clutch arm			
6	1	1911-1114-01	Guard			
7	1	1911-1115-01	Clutch lever			
8	1	1911-1116-01	Battery guide			
9	1	1911-1117-01	Gear housing			
10	1	1911-1118-01	Gasket			
11	1	1911-1119-01	Gear wheel			
12	1	1911-1120-01	Eccentric ring			
13	1	1911-1121-01	Gear			
14	1	1911-1122-01	Gear housing cover			
15	1	1911-1123-01	Spring			
16	2	1911-1124-01	Compression spring			
17	2	1911-1125-01	Compression spring			
18	4	1911-1126-01	Screw			
19	3	1911-1127-01	Screw			
20	4	1911-1128-01	Screw			
21	4	1911-1129-01	Screw			
22	1	1911-1130-01	Seal strip			
23	1	1911-1131-01	Handle switch			
24	1	1911-1132-01	Switch-rear handle			
25	1	1911-1133-01	El. motor			
26	1	1911-1134-01	Blade assy			
27	1	1911-1135-01	Holder			
38	1	..19-1952-11	Battery		14,4 volt	
39	1	1911-1110-01	Charger			
40	1	1911-1136-01	Charging station			