



Section: SWING 45S IH (XTE50) EURO 45S IH (Classic) EURO 470 IH (Clas

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	324-					
	709					
	504	721	344			
	769	723	759			
1	1		1117-1144-10		Deck-green	
1	1	1	1117-1144-01		Deck-yellow	
1	1	1	1117-1144-02		Deck-red	
2	1	1	1117-1160-01		Shaft-backside	
3	2	2	9595-0212-00		Locating pin	
4	2	2	1117-1304-01		Wheel protection ca	
5	1	1	1117-1174-01		Height adjust lever	
6	2	2	1111-2663-01		Wheel	
6		2	1111-2665-01		Wheel assy	Inkl. pos 84
7	2	2	9699-0037-02		Washer	
8	1	1	1117-3008-01		Baffle-rear	
9	12	12	9836-9516-12		Screw	
10		1	1117-1156-05		Rear flap-green	
10		1	1117-1156-01		Rear flap-yellow	
10	1	1	1117-1156-02		Rear flap-black	
11	1	1	1117-1143-01		Shaft	
12	1	1	1117-1126-01		Spring-rear flap	
13		1	1117-1155-01		Flap holder-yellow	
13	1	1	1117-1155-02		Flap holder-black	
13		1	1117-1155-05		Flap holder-green	
14	1	1	1117-3007-01		Baffle-front	
15	2	2	1117-1215-01		.Pin	
16	2	2	1117-1228-01		Adjusting lever	Inkl. pos 15
17	2	2	1117-1376-01		Wheel lever	
18	2	2	1117-1213-01		Sector	
19	2	2	1117-1182-01		Shoulder bolt	
20	2	2	1111-3163-01		Wheel	
21	2	2	1111-2804-03		Hub cap-white	
21	2	2	1111-2804-04		Hub cap-red	
21		2	1111-2804-01		Hub cap-yellow	
21	2	2	1111-2804-02		Hub cap-black	
22		2	1111-2815-01		Hub cap-yellow	
22	2	2	1111-2815-02		Hub cap-black	
22	2	2	1111-2815-03		Hub cap-white	
22	2	2	1111-2815-04		Hub cap-red	
23	6	6	1117-1131-01		Nut	
24	4	4	9699-0028-02		Flat washer	
25	4	4	1117-1364-01		Screw	
26	2	2	9898-0845-12		Screw	
27	1	1	1117-1355-01		Socket wrench	
28	2	2	9699-0025-02		Washer	
29	4	4	9579-0008-00		Cable holder	
30	2	2	1117-3194-01		Locking knob	
31	6	6	9799-0831-02		Nut	
32	1	1	9799-0631-02		Nut	
33	1	1	1117-1149-01		Handle-lower part	
34	1	1	1117-1223-01		Handle-upper part	
35	1	1	1117-3221-01		OPC lever	
36	1	1	1117-1374-01		Control handle	
37	1	1	1117-1157-02		Grassbag cover-blac	Inkl. pos 68
37		1	1117-1157-01		Grassbag cover-yell	Inkl. pos 68
37		1	1117-1157-05		Grassbag cover-gree	Inkl. pos 68
38	1	1	1117-1218-01		Lower grass bag	
39	1	2	9997-0830-16		Screw	
40	2	2	9716-0831-02		Nut	
41	3	3	9678-0009-02		Lock washer	
42	1	1	9600-0014-00		Key	
43	1	1	1117-1387-01		Blade holder	
44	1	1	1117-1203-01		Blade	
45	2	2	9836-9512-12		Screw	
46	1	1	1117-1065-01		Spring washer	
47	1	1	9987-5251-12		Screw	
48	2	2	9997-0614-16		Screw	
49	2	2	1117-1175-01		Washer	
50	1	1	1117-1120-01		Spring	
51	2	2	9591-0011-00		Pin	

Section: SWING 45S IH (XTE50) EURO 45S IH (Classic) EURO 470 IH (Clas

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		324-				
		709				
	504	721	344			
	769	723	759			
52	2	2	2	1117-1083-01	Safety ring	
53	4	4	4	1111-2830-01	Support washer	
54	2	2	2	1111-3075-01	Pinion-plastic whee	
55	1	1		1117-1191-01	Control cable	Inkl. pos 72
55			1	1117-1190-01	Clutch cable	Inkl. pos 72
56	1	1	1	1117-1114-01	Support	
57	2	2	2	9595-0258-00	Locating pin	
58	1	1	1	9865-0616-16	Screw	
59	1	1	1	1117-3017-01	V-belt	
60			1	1117-1268-01	Bolt	M8 x 40
60	1	1		9997-0840-16	Screw	
61	4	4	4	9699-0062-02	Flat washer	
62	1	1	1	1117-1147-01	Transmission cap	
63	1	1	1	1117-1095-01	Handle-upper part	
64	1	1	1	1117-3030-01	Assy kit	
65	1	1	1	1111-2927-01	Battery holder	
66	2	2	2	9549-0043-00	Ball bearing	
67	2	2	2	1111-3256-01	Drive key	
68	1	1	1	1117-1135-02	.Cover-black	
68		1	1	1117-1135-01	.Cover-yellow	
69	1	1	1	1117-3018-01	.Pulley	
70	1	1	1	1111-2382-01	.Pin	
71	1	1	1	1117-3016-01	Gear box assy	Inkl. pos 69, 70
72	1	1	1	1134-3203-04	.Cable protector	
73	1	1	1	1117-1183-01	Engine brake cable	
74	4	4	4	1111-1273-01	.Bushing	
75	1	1	1	1117-1116-01	Rope holder	
76	2	2	2	1111-3164-01	Wheel axle bolt	
77	4	4	4	1117-1193-01	Wheel bushing	
78	1	1	1	9948-0635-16	Screw	
79	1	1	1	1117-3222-01	Control lever	
80	1			1117-3184-01	Assy kit	
81	1			9948-0645-16	Screw	
82	1			1117-1189-01	Throttle control	
83	1			1117-1179-01	Bolt	
84			2	1111-9047-01	.Ball bearing kit	
85			4	9694-0003-00	Washer	
86			4	9549-0053-00	Ball bearing	