



STIGA
546D
SPARE PARTS

Section: TURBO 48-48S-48SE HANDLEBAR FRONT WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New	
		5288					
	5188	-17	5488 5489				
1	1	1	1	1	1111-2805-01	Front axle	
2	2	2	2	2	1111-1504-01	Retainer	
3	2	2	2	2	9947-0616-16	Screw	
4	1	1	1	1	1111-2818-01	Height adj.rod	
5	2	2	2	2	9675-0011-00	Starlock	
6	1	1	1	1	1111-2819-01	Spring	
10	2	2	2	2	1111-1138-01	Spring	
11	2	2	2	2	1111-2784-01	Wheel assy	
12	1	1	1	1	1111-9047-01	.Ball bearing kit	
13	2	2	2	2	1111-1184-01	..Bearing cone	
14	2	2	2	2	1111-2785-01	Wheel cover	
15	2	2	2	2	9699-0100-02	Washer	
16	2	2	2	2	9943-0612-16	Screw	
17	2	2	2	2	1111-3084-01	Hub cap-yellow	
20	2	2	2	2	1111-3021-01	Handlebar attachmen	
21	4	4	4	4	9795-3531-02	Nut	
22	1	1	1	1	1111-3022-01	Handle-lower	
23	4	4	4	4	1111-3023-01	Locking knob	
24	2	2	2	2	9899-3557-12	Screw	L = 57 mm
25	2	2	2	2	9899-3545-12	Screw	L = 45 mm
26	6	6	6	6	9699-0028-02	Flat washer	
27	2	2	2	2	9939-0820-16	Screw	
28	2	2	2	2	1111-3024-01	Attachment plate	
33	2	2	2	2	1111-0178-00	Reinforcement	
43	1	1	1	1	1111-2957-01	Handle-upper	
44	1	1	1	1	1111-3062-01	Eyelink	
47	1	1	1	1	9948-0640-16	Screw	L = 40 mm
48	1	1	1	1	9747-0631-02	Lock nut	
52	1	1	1	1	1111-2953-01	Control handle	
53	1	1	1	1	1111-2968-05	Engine brake cable	
54	1	1	1	1	1111-2969-01	Cable attachment	
56	1	1	2	3	1111-2018-01	Cable holder	
57	1	1	2	3	9836-9216-12	Screw	
61				2	9838-9512-12	Screw	
62				1	9400-0218-00	Battery	
63	1	1	1	1	1111-2927-01	Battery holder	
64				1	9400-0219-00	Charger	
69				1	1111-2825-01	Harness	
70				1	9400-0186-00	Starting switch ass	
71				1	1134-2848-01	.Ignition key	
74				2	9838-9522-12	Screw	
75				1	1111-2705-01	Cover	
78				1	1111-2707-01	Housing	
79				1	9401-0200-00	Cable holder	