



Section: SWEEPER ART.NO 13-1933-13 ART.NO 13-1934-13 TRANSMISSION

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------|--------------------|--------------------|-----|
| | 1933 | 1934 | | | | |
| 2 | 1 | 1 | 1134-2762-01 | Case | | |
| 4 | 1 | 1 | 1134-2763-01 | Transmission cover | | |
| 6 | 1 | 1 | 9500-9982-00 | Oil plug | | |
| 7 | 2 | 2 | 9591-0020-00 | Pin | | |
| 8 | 9 | 9 | 9997-0635-12 | Screw | | |
| 10 | 14 | 14 | 9739-0631-22 | Nut | | |
| 11 | 5 | 5 | 9997-0670-12 | Screw | | |
| 12 | 1 | 1 | 1134-2584-01 | Sprocket | | |
| 13 | 1 | 1 | 9907-1020-19 | Set screw | | |
| 14 | 1 | 1 | 9695-0006-00 | Washer | | |
| 16 | 2 | 2 | 9549-0045-00 | Ball bearing | | |
| 17 | 2 | 2 | 9404-0074-00 | Seal ring | | |
| 18 | 1 | 1 | 1134-2585-01 | Output shaft | | |
| 21 | 1 | 1 | 1134-2674-01 | Sprocket assy | Inkl. 22-30, 39-40 | |
| 22 | 1 | 1 | 1134-2587-01 | .Sprocket | | |
| 23 | 1 | 1 | 1134-2588-01 | .Shaft | | |
| 25 | 1 | 1 | 9600-0148-00 | .Flat key | | |
| 26 | 1 | 1 | 9650-0017-04 | .Retaining ring | | |
| 27 | 2 | 2 | 9695-0005-00 | .Washer | | |
| 30 | 2 | 2 | 9549-0017-00 | .Ball bearing | | |
| 31 | 1 | 1 | 9589-0013-00 | Chain | | |
| 32 | 1 | 1 | 1134-2589-01 | Chain tensioner | | |
| 33 | 1 | 1 | 1134-2590-01 | Compression spring | | |
| 34 | 1 | 1 | 1111-1706-01 | Clamp | | |
| 35 | 1 | 1 | 9943-0510-16 | Screw | | |
| 39 | 2 | 2 | 9549-0019-00 | .Ball bearing | | |
| 40 | 3 | 3 | 9695-0005-00 | .Washer | | |
| 42 | 1 | 1 | 9651-0040-04 | Retaining ring | | |
| 43 | 1 | 1 | 1134-2757-01 | Drive sheave | | |
| 44 | 1 | 1 | 9600-0145-00 | Flat key | | |
| 45 | 1 | 1 | 9699-0056-02 | Flat washer | | |
| 47 | 1 | 1 | 9958-0820-16 | Screw | | |
| 65 | 1 | | 1134-9041-01 | V-belt | = 9585-0067-00 | |
| 65 | | 1 | 1134-9042-01 | V-belt | = 9585-0068-00 | |
| 68 | | 2 | 1134-2796-01 | Screw | L = 270 mm | |
| 68 | 2 | | 1134-2796-02 | Screw | L = 355 mm | |
| 72 | 2 | 2 | 9591-0031-00 | Pin | | |
| 75 | 24 | 20 | 1134-3880-01 | Brush | | |
| 76 | 2 | 2 | 1134-3884-01 | Brush | | |
| 78 | 2 | | 1134-2798-02 | Carrier | | |
| 78 | | 2 | 1134-2798-01 | Carrier | | |
| 79 | 2 | 2 | 1134-2619-01 | Washer | | |
| 82 | 2 | 2 | 1134-2620-01 | Washer | | |
| 83 | 8 | 8 | 9942-0825-16 | Screw | | |
| 84 | 8 | 8 | 9632-0509-00 | Pop rivet | | |
| 85 | 1 | 1 | 9404-0073-00 | Seal ring | | |
| 92 | | 1 | 1134-1446-01 | Spring | | |
| 93 | | 1 | 1134-9027-01 | Tension roller | | |
| 94 | | 1 | 9699-0035-02 | .Flat washer | | |
| 95 | | 1 | 9997-1035-16 | Screw | | |
| 96 | | 2 | 9699-0035-02 | Flat washer | | |