



Section: ESTATE SENATOR ESTATE PRESIDENT STEERING

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2531	2532				
1	1	1	1136-0466-01	Front wheel axle as	Inkl. pos 2, 3	
2	4	4	1136-0121-01	.Bushing		
3	2	2	9501-0500-00	.Grease joint		
4	1	1	1136-0485-01	Stub axle-RH		
5	1	1	9652-0015-04	Retaining ring		
6	1	1	1136-0486-01	Stub axle-LH		
7	1	1	1136-0349-01	Tie rod		
8	2	2	1136-0092-01	Ball joint		
9	2	2	9747-1031-02	Lock nut		
11	1	1	1136-0188-01	Steering arm		
12	1	1	9997-1055-12	Screw		
13	1	1	9747-1031-02	Lock nut		
14	1	1	1136-0165-01	Spacer		
15	1	1	9997-1260-02	Screw		
16	2	2	1136-0016-01	Washer		
17	1	1	9683-0055-02	Lock washer		
18	1	1	9799-1231-02	Nut		
31	1	1	1136-0335-01	Support		
32	4	4	9997-0816-16	Screw		
33	4	4	9747-0831-02	Lock nut		
34	1	1	1136-0541-01	Support		
35	4	4	9847-8216-16	Screw		
36	1	1	1136-0124-01	Bushing		
37	1	1	1136-0250-01	Steering column		
38	1	1	1136-0263-01	Steering pinion		
39	1	1	9595-0262-00	Locating pin		
40	1	1	9699-0037-02	Washer		
41	1	1	1136-0008-01	Lock plate		
42	1	1	1136-0128-01	Bushing		
43	1	1	1136-0246-01	Stud bolt		
44	1	1	9799-1031-02	Nut		
45	2	2	1136-0310-01	Washer		
46	1	1	1136-0320-01	Steering sector		
47	1	1	1136-0311-01	Washer		
48	1	1	1136-0083-01	Elastic washer		
49	1	1	9699-0035-02	Flat washer		
50	2	2	9799-1031-02	Nut		
51	2	2	1136-0087-01	Washer		
52	1	1	1136-0015-01	Washer		
54	1	1	9747-1031-02	Lock nut		
55	1	1	1136-0111-01	Steering rod		
56	2	2	1136-0092-01	Ball joint		
58	2	2	9747-1031-02	Lock nut		
59		1	1136-0279-01	Micro protection		
60		2	9847-7813-16	Screw		
61	2	2	9699-0035-02	Flat washer		
72	2	2	1136-0454-01	Rim		
73	4	4	1136-0157-01	Bearing		
74	2	2	1136-0269-01	Tire (Turf Saver)		
74	2	2	1136-0271-01	Tire (Deli)		
75	2	2	1136-0305-01	Washer		
76	2	2	9652-0015-04	Retaining ring		
77	2	2	1136-0081-01	Hub cap		
78	2	2	1136-0359-01	Valve		