



Section: SP 370-SP 410 CYLINDER CRANKSHAFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	4113	4114				
1	1	1	1911-3280-01		Nut	
2	1	1	1911-3268-01		Washer	
3	1	1	1911-3567-01		Flywheel	
4	1	1	1911-3048-01		Flywheel key	
5a	1	1	1911-3301-01		Seal ring	
5b	1	1	1911-3302-01		Seal ring	
6	2	2	1911-3297-01		Ball bearing	
7	2	2	1911-3072-01		Washer	
8	1	1	1911-3532-01		Crankshaft assy	Inkl. pos 19
9	1	1	1911-3488-01		Dust guard	
10	1	1	1911-3538-01		Clutch	
11	1	1	1911-3041-01		Needle bearing	
12	1	1	1911-3514-01		Sprocket	0.325"
13	1	1	1911-3338-01		Sprocket washer	
14	1	1	1911-3330-01		Circlip	
15	2	2	1911-3069-01		.Lock ring	
18	1	1	1911-3051-01		.Piston pin	
19	1	1	1911-3042-01		.Needle bearing	
20	4	4	1911-3006-01		Screw	
21	4	4	1911-3274-01		Washer	
22	1	1	1911-3304-01		.Piston ring	
23	4	4	1911-3022-01		Nut	
24	1	1	1911-3597-01		Cylinder-piston ass	Inkl. pos 15, 18, 2
25	1	1	9400-0258-00		Spark plug	Champion CJ7Y
26	1	1	1911-3546-01		Spark plug cover	
27	1	1	1911-3421-01		Spring	
28	1	1	1911-3434-01		Protection	
29	1	1	1911-3053-01		Stop switch	
32	1	1	1911-3321-01		Ground cable	
33	1	1	1911-3320-01		Electronic coil	
34	1	1	1911-3418-01		Spring	
35	2	2	1911-3017-01		Washer	
36	2	2	1911-3251-01		Screw	
37	1	1	1911-3247-01		Screw	