



Section: TURBO 43-43S TRANSMISSION REAR WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1190	1290				
1	1	1	1111-3114-01		Rear axle	
2	2	2	1111-2814-01		Bushing	
3	4	4	9947-0616-16		Screw	
4	5	5	9838-9522-12		Screw	
5	1	1	1111-2798-01		Height adj.quadrant	
6	1	1	1111-2816-01		Height adj.lever	
7	1	1	1111-2817-01		Lever knob	
8	2	2	9943-0612-16		Screw	
10	2	2	1111-2665-01		Wheel assy	
11	2	2	1111-9047-01		.Ball bearing kit	
12	2	2	1111-1184-01		..Bearing cone	
15	2	2	9699-0100-02		Washer	
16	2	2	9943-0612-16		Screw	
17	2	2	1111-3085-01		Hub cap-yellow	
20	2	2	1111-3060-01		Spring	
21	2		1111-2782-01		Wheel cover	
22		2	1111-2561-01		Cover plate	
23		1	1111-2915-01		Engine belt pulley	
24		1	9910-0612-16		Set screw	
26		1	1111-3111-01		Transmission assy	
27		1	1111-3047-01		Belt pulley	
28		1	9595-0235-00		Locating pin	
30		1	1111-2822-01		Tension spring	
31		2	1111-2382-01		Pin	
32		2	1111-3256-01		Drive key	
33		2	9404-0083-00		Seal ring	
36		4	9695-0013-00		Washer	
37		2	1111-2829-01		Lock washer	
38		2	1111-3075-01		Pinion plastic whee	
39		2	1111-2830-01		Support washer	
41		2	9652-0010-04		Snap ring	
45		1	1111-2967-02		Clutch cable	
47		1	1111-2954-01		Control handle	
48		1	1111-2969-01		Cable attachment	
49		1	9948-0640-16		Screw	L = 40 mm
50		1	9747-0631-02		Lock nut	
51	1		1111-2924-02		Axle	
52	2		9675-0017-02		Lock washer	
53	1	1	1111-3102-01		Cover-yellow	
66		1	1111-9053-01		Drive belt	