



Section: TURBO 48-48S-48SE MAJOR ALU 48S TRANSMISSION REAR WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

Pos.	Quantity	Spare part No	Description	Kit	Notes	New	
		5288					
	5188	-18	5289	5688			
1	1	1	1	1	1111-2808-01	Rear axle	
2	2	2	2	2	1111-2814-01	Bushing	
3	4	4	4	4	9947-0616-16	Screw	
4	5	5	5	5	9838-9522-12	Screw	
5	1	1	1	1	1111-2798-01	Height adj.quadrant	
6	1	1	1	1	1111-2816-01	Height adj.lever	
7	1	1	1	1	1111-2817-01	Lever knob	
8	2	2	2	2	9943-0612-16	Screw	
9	2				9699-0037-02	Washer	
10	2	2	2	2	1111-2665-01	Wheel assy	
11	1	1	1	1	1111-9047-01	.Ball bearing kit	
12	2	2	2	2	1111-1184-01	. .Bearing cone	
15	2	2	2	2	9699-0100-02	Washer	
16	2	2	2	2	9943-0612-16	Screw	
17	2	2	2		1111-3085-01	Hub cap-yellow	
17				2	1111-3085-06	Hub cap-black	
20	2	2	2	2	1111-3060-01	Spring	
21	2				1111-2782-01	Wheel cover	
22		2	2	2	1111-2561-01	Cover plate	
23		1	1	1	1111-2915-01	Engine belt pulley	
24		1	1	1	9910-0612-16	Set screw	
25		1	1	1	1111-9061-01	V-belt	
26		1	1	1	1111-3046-01	Transmission	
27		1	1	1	1111-3047-01	Belt pulley	
28		1	1	1	9595-0235-00	Locating pin	
30		1	1	1	1111-2822-01	Tension spring	
31		2	2	2	1111-2382-01	Pin	
32		2	2	2	1111-3256-01	Drive key	
33		2	2	2	9404-0083-00	Seal ring	
36		4	4	4	9695-0013-00	Washer	
37		2	2	2	1111-2829-01	Lock washer	
38		2	2	2	1111-3075-01	Pinion-plastic whee	
39		2	2	2	1111-2830-01	Support washer	
41		2	2	2	9652-0010-04	Snap ring	
45		1	1	1	1111-2967-01	Clutch cable	
47		1	1	1	1111-2954-01	Control handle	
48		1	1	1	1111-2969-01	Cable attachment	
49		1	1	1	9948-0640-16	Screw	L = 40 mm
50		1	1	1	9747-0631-02	Lock nut	
51	1				1111-2924-01	Shaft	
52	2				9675-0017-02	Lock washer	
53	1	1	1		1111-2794-01	Cover-yellow	
53				1	1111-2794-02	Cover-black	