



Section: ESTATE SENATOR ESTATE PRESIDENT BODY WORK

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2531	2532				
1	1	1	1136-0472-01		Engine hood	Inkl. pos 2, 5, 6
2	1	1	1136-0262-01		.Plate	
3	2	2	1136-0230-01		Bolt	
4	2	2	1136-0009-01		Lock plate	
5	1	1	1136-0223-01		.Lights parabola	
6	1	1	1136-0198-01		.Lamp cover	
8	2	2	1136-0206-01		Hood spring	
9	2	2	9847-8019-16		Screw	
10	2	2	1136-0179-01		Grommet	
11	1	1	1136-0155-01		Dashboard	
14	2	2	9848-8013-16		Screw	
15	2	2	1136-0010-01		Lock plate	
16	3	3	9836-9618-12		Screw	
17	1	1	1136-0331-01		Dashboard support	
18	1		1136-0475-01		Wheel cover-yellow	Inkl. pos 19, 20
18		1	1136-0476-01		Wheel cover	Inkl. pos 19, 20
19	1	1	1136-0148-01		.Footboard cover-RH	
20	1	1	1136-0147-01		.Footboard cover-LH	
21	6	6	9836-9635-12		Screw	
22	4	4	9836-9618-12		Screw	
23	1	1	9836-9525-12		Screw	
24	5	5	9699-0060-02		Flat washer	
25	4	4	9699-0085-02		Flat washer	
31	1	1	1136-0440-01		Throttle control	
32	2	2	9997-0412-16		Screw	
33	2	2	9683-0010-02		Washer	
34	1	1	1136-0192-01		Handle	
35	1	1	9865-0412-16		Screw	
36	1	1	9799-0431-02		Nut	
41	1	1	1136-0315-01		Seat	
42	1	1	1136-0336-01		Support	
43	1	1	1136-0252-01		Seat plate	
44	4	4	9997-0820-16		Screw	
45	4	4	9683-0030-02		Lock washer	
46	4	4	9699-0056-02		Flat washer	
51	1	1	1136-0360-01		Steering wheel	
52	1	1	9595-0272-00		Pin	
61	1	1	1136-0143-01		Cover	
62	1	1	1136-0277-01		Guard-RH	
63	1	1	1136-0278-01		Guard-LH	
64	6	6	9836-9618-12		Screw	
65	2	2	9847-8216-16		Screw	
66	2	2	9836-9618-12		Screw	
67	3	3	9836-9618-12		Screw	
68	4	4	9836-9618-12		Screw	
71	1	1	1136-0142-01		Grass catcher cover	
72	4	4	9847-8116-16		Screw	
73	4	4	9699-0035-02		Flat washer	
81	1	1	1136-0275-01		Guard-upper	
82	1	1	1136-0276-01		Guard-lower	
83	2	2	9847-8038-16		Screw	
84	2	2	9699-0024-02		Flat washer	
85	2	2	1136-0010-01		Lock plate	
91	1	1	1136-0318-01		Fuel tank	
92	1	1	1136-0344-01		Tank cap	
93	1	1	1136-0327-01		Tank support	
94	1	1	9848-8013-16		Screw	