



## Section: PARK PRO 16 STEERING

| Pos. | Quantity | Spare part No | Description         | Kit | Notes   | New |
|------|----------|---------------|---------------------|-----|---------|-----|
|      | 6216     |               |                     |     |         |     |
| 1    | 1        | 1134-2820-06  | Chain               |     | 83 länk |     |
| 2    | 3        | 1134-2820-02  | Chain               |     | 41 länk |     |
| 3    | 1        | 1134-2820-04  | Chain               |     | 45 länk |     |
| 4    | 2        | 1134-3550-01  | End nipple          |     |         |     |
| 5    | 4        | 1134-3565-01  | Connection nipple   |     |         |     |
| 6    | 10       | 1134-2824-01  | Chain lock          |     |         |     |
| 7    | 2        | 1134-3817-01  | Compression spring  |     |         |     |
| 8    | 2        | 9699-0090-02  | Flat washer         |     |         |     |
| 9    | 2        | 9747-0831-02  | Lock nut            |     |         |     |
| 10   | 4        | 1134-2816-01  | Sprocket            |     |         |     |
| 11   | 4        | 1134-0041-02  | Idler wheel bush    |     |         |     |
| 12   | 4        | 9699-0035-02  | Flat washer         |     |         |     |
| 13   | 2        | 9997-1050-16  | Screw               |     |         |     |
| 14   | 2        | 9897-1040-12  | Screw               |     |         |     |
| 15   | 4        | 9739-1031-22  | Nut                 |     |         |     |
| 16   | 3        | 1134-3547-01  | Sprocket            |     |         |     |
| 17   | 2        | 1134-0041-01  | Bushing             |     |         |     |
| 18   | 2        | 1134-3022-01  | Cable holder        |     |         |     |
| 19   | 2        | 9997-1030-16  | Screw               |     |         |     |
| 20   | 2        | 9739-1031-22  | Nut                 |     |         |     |
| 21   | 1        | 1134-4120-03  | Steering console    |     |         |     |
| 22   | 4        | 9897-0820-16  | Screw               |     |         |     |
| 23   | 4        | 9739-0831-22  | Nut                 |     |         |     |
| 24   | 1        | 1134-3085-01  | Steering column-low |     |         |     |
| 25   | 2        | 9549-0017-00  | Ball bearing        |     |         |     |
| 26   | 2        | 9893-0616-16  | Screw               |     |         |     |
| 27   | 1        | 1134-3084-01  | Steering rod        |     |         |     |
| 28   | 1        | 1134-2837-02  | Spacer              |     |         |     |
| 29   | 1        | 9695-0011-00  | Washer              |     |         |     |
| 30   | 1        | 1134-4155-01  | Steering wheel      |     |         |     |
| 31   | 1        | 1134-4218-01  | Steering tube-inner |     |         |     |
| 32   | 1        | 1134-4138-01  | .Catch              |     |         |     |